

# INSTALLATION OPERATION AND SERVICE MANUAL



## GAS FIRED COMMERCIAL CONDENSING STAINLESS STEEL TUBE BOILERS *DynaForce SERIES*



### HYDRONIC HEATING

*Models; DRH300, 350 400, 500, 600, 800, 1000, 1200,  
1400, 1600, 1800, 2000, 2500, 3000, 3500, 4000, 4500,  
5000*



### HOT WATER HEATER

*Models; DRW300, 350 400, 500, 600, 800, 1000, 1200,  
1400, 1600, 1800, 2000, 2500, 3000, 3500, 4000, 4500,  
5000*



#### **WARNING:**

If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury or death

Do not store or use gasoline or other flammable vapours and liquids in the vicinity of this or any other appliance.

#### **WHAT TO DO IF YOU SMELL GAS**

- Do not try to light any appliance,
- Do not touch any electrical switch; do not use any phone in your building,
- Immediately call your gas supplier from a neighbour's phone. Follow the gas supplier's instructions,
- If you cannot reach your gas supplier, call the fire department.

**Qualified installer, service agency or the gas supplier must perform installation and service.**

**To the Installer:** After installation, these instructions must be given to the end user or left on or near the appliance.

**To the End User:** This booklet contains important information about this appliance. Retain for future reference.



## **CAMUS HYDRONICS LTD.**

6226 Netherhart Road, Mississauga, Ontario, L5T 1B7



## Contents

PART 1	GENERAL INFORMATION .....	1
1.1	INTRODUCTION .....	1
1.2	SPECIAL INSTRUCTIONS TO OWNER .....	1
1.3	CHECKING EQUIPMENT .....	1
1.5	HOW IT OPERATES (SEQUENCE OF OPERATION).....	1
1.5.2	HEAT TRANSFER PROCESS.....	2
1.5.3	END OF SEQUENCE.....	2
1.6	CODES.....	3
1.7	WARRANTY.....	3
1.8	REMOVAL OF EXISTING APPLIANCE.....	3
1.9	BOILER ROOM OPERATING CONDITION .....	4
1.10	CLEARANCE FROM COMBUSTIBLE MATERIAL.....	4
1.11	INSTALLATION PROCEDURE AND LOCATION OF UNIT .....	5
PART 2	VENTING.....	8
1.1	GENERAL VENTING GUIDE.....	8
2.1.3	CATEGORY II AND CATEGORY IV VENTING.....	8
2.1.4	VENTING GUIDELINES FOR CATEGORY II AND/OR IV VENTING .....	8
2.1.5	APPROVED VENTING MATERIALS.....	8
2.1.6	VENT TERMINATION CLEARANCES .....	9
2.1.7	INLET CAP FOR ROOFTOP TERMINATION .....	9
2.1.8	LOCATION OF A ROOFTOP AIR INLET AND VENT CAPS .....	9
2.1.9	AIR INLET DAMPER.....	10
2.1.10	MASONARY CHIMNEY INSULATIONS.....	10
2.1.11	VERTICAL VENTING TERMINATION.....	10
2.1.12	COMBINED COMBUSTION AIR INLET .....	10
2.1.13	DRAIN TEE .....	10
2.2	CONVENTIONAL VENTING (INDOOR) INSTALLATIONS.....	11
2.2.1	AIR REQUIRED FOR COMBUSTION AND VENTILATION.....	11
2.2.2	EXHAUST FANS.....	11
2.3	OUTDOOR VENTING.....	11
2.4	THRUWALL VENTING.....	12
2.4.1	THRUWALL VENT TERMINAL & THRUWALL INTAKE AIR TERMINAL .....	12
2.4.2	LOCATION OF A THRUWALL VENT TERMINATION .....	12
2.4.3	LOCATION OF A "THRUWALL" AIR INLET TERMINAL.....	12
2.4.4	LENGTH OF AIR INLET PIPE .....	12
PART 3	GAS CONNECTION.....	13
3.1	GAS CONNECTION.....	13
3.2	GAS PIPING.....	13
3.3	INSTALL PIPING.....	13
3.4	AIR/GAS RATIO VALVE .....	13
3.4	DIFFERENTIAL AIR PRESSURE .....	14
3.5	GAS MANIFOLD DIFFERENTIAL PRESSURE ADJUSTMENT (DR2500 – DR5000) .....	14
3.6	CHECKING GAS SUPPLY PRESSURE.....	15
3.7	CHECKING DIFFERENTIAL AIR AND GAS PRESSURES (DR2500 – DR5000) .....	15
3.8	GAS TRAIN AND CONTROLS .....	16
3.9	VENTING OF GAS VALVES AND PRESSURE SWITCHES.....	16
3.10	BURNER .....	16
PART 4	WATER CONNECTION .....	17
4.1	FREEZE PROTECTION.....	17
4.2	WARNING REGARDING CHILLED WATER SYSTEMS .....	17
4.3	INLET AND OUTLET CONNECTIONS.....	18
4.4	MINIMUM PIPE SIZE REQUIREMENTS.....	18
4.5	PRIMARY HEAT EXCHANGER .....	18
4.6	LOW WATER TEMPERATURE SYSTEMS.....	18
4.7	INSTANTANEOUS WATER HEATER .....	18

4.10	WATER FLOW SWITCH (shipped loose)	19
4.11	LOW WATER CUTOFF (If Equipped)	19
4.12	RELIEF VALVE (shipped loose)	19
4.14	CIRCULATING PUMP SELECTION	20
4.14.1	CIRCULATING PUMP OPERATION PRIMARY HEAT EXCHANGER	20
PART 5	ELECTRICAL & CONTROLS	20
5.1	ELECTRICAL CONECTIONS	20
5.2	VARIABLE FREQUENCY DRIVE (DR1200 – 5000)	21
5.3	DIFFRENTIAL AIR PRESSURE SWITCH	21
5.4	BLOCKED FLUE SWITCH	21
5.5	HIGH and LOW GAS PRESSURE SWITCHES (Optional)	21
5.6	HIGH LIMIT	21
5.7	IGNITION CONTROL MODULE	21
5.8.1	SERVICE PARTS	21
5.7.2	IGNITION MODULE LOCKOUT FUNCTIONS	22
5.8.1	Service Parts	22
5.8.2	Ignition Module Lockout Functions	22
5.1	ERROR TABLE	22
PART 6	CONTROL PANEL	24
6.1	APPLIANCE TEMPERATURE CONTROLLER	24
6.2	OPERATION MENU	25
6.4	DETAILS MENU	27
6.5	CONFIGURE MENU	29
6.2	VARIABLE FREQUENCY DRIVE (DR1200 - 5000)	36
PART 7	COMPONENTS	37
7.1	HOT SURFACE IGNITER (GLOW BAR)	37
7.2	FLAME SENSOR	37
7.3	COMBUSTION AIR FAN	37
7.4	INNER JACKET	37
7.5	OUTER JACKET	37
7.6	VENTING TRANSITION	37
PART 8	FIELD STARTUP PROCEDURE	38
8.1	CHECKING THE INSTALLATION	38
8.2	CHECKING THE CONSTRUCTION	38
8.3	GAS VALVE ADJUSTMENT PROCEDURE	38
8.4	COMISSIONING APPLIANCE	40
8.5	CASCADE SETUP	40
PART 9	TROUBLE SHOOTING	42
PART 10	MAINTANANCE	45
10.1	EXAMINE THE VENTING SYSTEM	45
10.2	VISUALLY CHECK MAIN BURNER FLAMES	45
10.3	FLUE GAS PASSAGEWAYS CLEANING PROCEDURES	45
10.4	CONDENSATION TREATMENT	45
10.4.1	CONDENSATE VOLUME	45
10.5	BURNER MAINTENANCE	46
10.5.1	BURNER REMOVAL AND CLEANING	46
10.5.2	BURNER CLEANING PROCEDURE	46
10.6	CHANGING THE HOT SURFACE IGNITER	46
10.6.1	RE-INSTALLING THE IGNITER	47
10.7	HEAT EXCHANGER INSPECTION	47
10.9	RE-INSTALL HEAT EXCHANGER	47
10.10	COMBUSTION AIR FAN	47
10.11	COMBUSTION AND VENTILATION AIR	47
10.12	CONTROL CIRCUIT VOLTAGE	47
10.13	COMBUSTIBLE MATERIALS	47
10.14	FREEZE PROTECTION	47
10.15	FREEZE PROTECTION FOR A HEATING BOILER SYSTEM (Optional)	48
PART 11	INSTALLATIONS	48
11.1	CHECKING THE INSTALLATION	48
11.2	CHECKING THE INSTALLTION	48

11.3	HEATING BOILER INSTALLATIONS .....	49
11.4	WATER CONNECTIONS.....	49
11.5	PIPING LENGTHS .....	49
11.6	INTERMITTENT PUMP OPERATION .....	49
11.7	SUMMARY .....	49
11.8	DOMESTIC HOT WATER HEATER .....	50
11.9	WATER VELOCITY CONTROL.....	50
11.10	TEMPERATURE RISE AT FULL FIRING RATE .....	50
11.11	WATER HEATERS .....	50
PART 12	EXPLODED VIEW.....	52
PART 13	ELECTRICAL DIAGRAMS .....	58
	CONDENSING BOILER LIMITED WARRANTY .....	60


# PART 1 GENERAL INFORMATION

## 1.1 INTRODUCTION

The **DynaForce** is a condensing fan assisted appliance based on push through design which offers several venting options. Heat output is controlled by a one to one air/gas ratio control gas valve which provides seamless modulation. The DynaForce provides central heating and/or domestic hot water at working pressure up to 160 PSI. It is designed for use with a fully pumped and pressurized system. The boiler/water heater will automatically modulate to provide heat outputs between 100% and down to 20% .

The DynaForce works on the principle of differential pressure. The operation of the fan will generate a differential pressure, which the gas/air ratio control gas valve will match on the gas side. The steady state efficiency is maintained across the entire range of modulation. Air and gas are metered in precise proportion (1:1 Ratio) to modulation signal, allowing combustion characteristics which determine efficiency to remain the same over entire operating range.

Figure 1: DynaForce



## 1.2 SPECIAL INSTRUCTIONS TO OWNER

This manual supplies information for the installation, operation and servicing of the appliance. It is strongly recommended that this manual be reviewed completely before proceeding with an installation

### CAUTION

It is important that all gas appliances are installed by a competent person. It is in your own interest and that of safety to ensure that all local codes, and all the following "NOTES" and "WARNINGS" is complied with. To Install, service or adjust this appliance, it is imperative that a competent serviceman that is qualified by Camus Hydronics utilize a combustion analyzer with CO<sub>2</sub>, CO, and draft gauge, to set the appliance according to Camus Hydronics recommendation, prior to commissioning.

### NOTE

RETAIN THIS MANUAL FOR FUTURE REFERENCE

## 1.3 CHECKING EQUIPMENT

Check for signs of shipping damage upon receiving equipment. Pay particular attention to parts accompanying the boiler, which may show signs of being hit or otherwise being mishandled. Verify total number of pieces shown on packing slip with those actually received. In case there is damage or a shortage, immediately notify carrier.

Figure 2: Checking the DynaForce



Do not attempt to pry any panel off. To begin disassembly you must first remove the two ¼" bolts from the top of the lid. Only then will you be able to remove the lid and disassemble the three outer panels.

Once you have removed the lid carefully check and confirm that all ¼" copper tubing connections are intact and have not broken or loosened in shipment. Leaks at any connections on these lines will result in erratic appliance operation.

## 1.5 HOW IT OPERATES (SEQUENCE OF OPERATION)

- 1 The power switch is placed in the "ON" position.
- 2 Supply power connection as per table 7.
- 3 120 VAC power is supplied to the control transformer and Ignition Module on all models.
- 4 24 VAC is supplied to all low voltage controls for all models.
- 5 After the appliance water pump starts, flow is proven by the flow switch. The low water cutoff and flow switch are shipped loose .The flow switch is to be mounted in a tee at the outlet of the appliance. Take care to properly trim the flow switch paddles so as not to jam the switch in the tee. The normally open dry contacts in the low water cutoff (LWCO) are to be wired in series with the normally open contacts of the flow switch. Locate the probe type LWCO in the piping above the boiler inlet/outlet connection. In all cases check with local codes.
- 6 The DynaForce controller receives a call for heat via the local or remote and the Demand parameter reads Central Heating or DHW.
- 7 The local thermostat initiates a start-up sequence once it receives a heat demand. If the appliance is equipped with remote operation if remote operation is enabled, a heat demand is available only if the remote system calls for heat.
- 8

9 **DR 300 – DR 1000:** The DynaForce controller energizes the pump contacts and starts to ramp up the voltage to the electrically commutated DC motor of the combustion fan after internal safety checks are satisfied.

**DR1200-DR5000:** The local thermostat energizes the motor stop/start relay which closes the initiate contacts to the variable frequency drive (VFD) which starts to ramp up the frequency to the 230V 3 phase motor of the combustion fan. If the VFD is not in fault mode the frequency will accelerate at the preprogrammed rate towards 60 Hz using the modulating signal provided by the on board modulating control or the remote operating system if the local/remote switch has been ordered.

10 If temperature high limit, water flow and airflow switches are closed the fan will run at pre-purge speed until the pre-purge timer is satisfied. Once complete the DynaForce will target the ignition fan speed.

11 **DR 300 – DR 1000:** The direct spark igniter sparks for 2 seconds without gas and continues to spark for an additional 4 seconds with the gas valve opened with the fan running at ignition speed. The fan is kept at ignition speed until the stabilization timer is satisfied.

**DR 1200 - DR 5000:** The DynaForce controller will activate the pilot valve, whereupon a proof current of 0.8µA for 22 seconds. If the flame signal is maintained this will activate the main gas valve. The fan is kept at ignition speed until the stabilization timer is satisfied.

12 If the proof current is not reached the module will stop the ignition sequence after the trial for ignition.

13 The fan speed will slowly decrease as the heat request nears the heat demand. The modulation ate is controlled via Pulse Width Modulation (DR300 – 1000) and a 4-20mA signal (DR1200 – 5000). If the heat demand is sustained for a long duration of time the boiler will get to a point of steady-state and the fan will rotate at constant speed.

14 When the heat demand is satisfied or is removed the burner will shut off and the fan speed will ramp up to the preset Post-Purge speed until the Post-Purge timer is satisfied.

15 The pump continues to circulate until the post-pump time is satisfied.


16 The boiler will then go into Standby as it waits for next heat demand.

Note:

1. If a flame signal is detected at the end of the pre-purge period a lockout will occur.
2. If at the end of the safety period (6 sec) no flame is detected the control will go to post-purge to remove the unburned gas. After this, a re-ignition attempt is started following the same schedule. The number of re-ignition attempts is limited to 2 after which a lockout occurs.
3. The burner can only be on continuously for a period of 24 hours. After this the burner is switched off and a restart sequence follows.
4. Sparkling stops 2 seconds before the end of the ignition period to allow for ionization detection.

The ignition cycle is shown in the table below.

**Figure 3: DynaForce Ignition Cycle**



### 1.5.2 HEAT TRANSFER PROCESS

- 1 Burner Input continues to increase until water temperature reaches the Set Point temperature.
- 2 Burner Input may stabilize at a fixed rate where demand equals input.
- 3 Burner Input will decrease rate when water temperature approaches temperature Set Point.

### 1.5.3 END OF SEQUENCE

- 1 Set Point temperature is satisfied.
- 2 Power to the gas valves is turned off.
- 3 Combustion Air Fan ramps to a stop over the factory preprogrammed time period of 60 seconds.
- 4 Thermostat is now in a standby mode waiting for the next "Call for Heat".

<b>WARNING</b>
To minimize the possibility of serious personal injury, fire or damage to your appliance, never violate the following safety rules.

<b>WARNING</b>
<b>IMPROPER INSTALLATION, ADJUSTMENT, ALTERATION, SERVICE OR MAINTENANCE</b> can cause injury or property damage. Refer to this manual. For additional information, consult a qualified installer, service agency or gas supplier.

<b>DO NOT</b>
Do not use this appliance if any part of it has been <b>under water</b> . The possible damage to a flooded appliance can be extensive and present numerous safety hazards. Any appliance that has been <b>under water</b> must be replaced

<b>WHAT TO DO IF YOU SMELL GAS</b>
Do not try to light any appliance. • Do not touch any electric switch: do not use any phone in your building. • Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions. • If you cannot reach your gas supplier, call the fire department.

<b>IMPORTANT</b>
Consult and follow local Building and Fire Regulations and other Safety Codes that apply to this installation. Contact the local gas utility company to authorize and inspect all gas and flue connections.

**Installation and service must be performed by Camus qualified factory trained service technicians.**

<b>WARNING</b>
Should overheating occur or the gas supply fails to shut off, <b>DO NOT</b> turn off or disconnect the electrical supply to the pump. Shut off the gas supply at a location external to the appliance.

- Boilers and water heaters are heat producing appliances. To avoid damage or injury, do not store materials against the appliance or the vent-air intake system. Use proper care to avoid unnecessary contact (especially children) with the appliance and vent-air intake components.
- Never cover your appliance, lean anything against it, store trash or debris near it, stand on it or in any way block the flow of fresh air to your appliance.
- **UNDER NO CIRCUMSTANCES** may flammable materials such as gasoline or paint thinner be used or stored in the vicinity of this appliance, vent-air intake system or any location from which fumes could reach the appliance or vent-air intake system.
- A gas appliance that draws combustion air from the equipment room where it is installed must have a supply of fresh air circulating around it during burner operation for proper gas combustion and proper venting.

## 1.6 CODES

The equipment shall be installed in accordance with those installation regulations in force in the local area where the installation is to be made. These shall be carefully followed in all cases. Authorities having jurisdiction shall be consulted before installations are made. In the absence of such requirements, the installation shall conform to the latest edition of the National Fuel Gas Code, ANSI Z223.1 and/or CAN/CGAB149 Installation Code. All electrical wiring must be done in accordance with the requirements of the authority having jurisdiction or, in the absence of such requirements, with national electrical code, ANSI/NFPA70 and/or the Canadian electrical code part 1 CSA C22.1. Where required by the authority having jurisdiction, the installation must conform to American Society of Mechanical Engineers Safety Code for Controls and Safety Devices for Automatically Fired Boilers, ASME CSD-1. All boilers conform to the latest edition of the ASME Boiler and Pressure Vessel Code, Section II. Where required by the authority having jurisdiction, the installation must comply with the CSA International, CAN/CGA-B149 and/or local codes. This appliance meets the safe lighting performance criteria with the gas manifold and control assembly provided, as specified in the ANSI standards for gas-fired units, ANSI Z21.13.

## 1.7 WARRANTY

- Factory warranty (shipped with unit) does not apply to units improperly installed or improperly operated.
- Factory warranty shall apply only when the appliance is installed in accordance with local plumbing and building codes, ordinances and regulations, the printed instructions provided with it and good industry practices.
- Excessive pitting and erosion on the inside of the stainless steel tube may be an indication of an undersized heater or may be caused by too high a **water velocity** through the tubes and is not covered by the manufacturer's warranty (See Boiler Flow Rates and Temperature Rise for flow requirements).
- Using or storing **corrosive chemicals** in the vicinity of this appliance can rapidly attack the stainless steel tubes and coils and voids warranty.
- Damage caused by **freezing or dry firing** voids

warranty.

- This appliance is not to be used for **temporary heating** of buildings under construction.
- The manufacturer shall **NOT** be held liable for any personal injury or property damage due to ice formation or the dislodging of ice from the vent system or the vent termination

## 1.8 REMOVAL OF EXISTING APPLIANCE

When an existing appliance is removed from a common venting system, the common venting system is likely to be too large for proper venting of the appliances remaining connected to it. At the time of removal of an existing appliance, the following steps must be followed with each appliance remaining connected to the common venting system placed in operation, while the other appliances remaining connected to the common venting system are not in operation.

- Seal any unused openings in the common venting system.
- Visually inspect the venting system for proper size and horizontal pitch and determine that there is no blockage, restriction, leakage, corrosion or other deficiency, which could cause an unsafe condition.
- Insofar as is practical, close all building doors and windows and all doors between the spaces in which the appliances remaining connected to the common venting system are located and other spaces of the building. If applicable turn on the clothes dryers and any appliances not connected to the common venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate a summer exhaust fan. Close fireplace dampers.
- Place in operation the appliance being inspected. Follow the lighting instructions. Adjust thermostat so that appliance operates continuously.
- If provided, test for spillage at the barometric damper relief opening after 5 minutes of main burner operation. Use a cold mirror, the flame of a match, or candle or smoke from a cigarette.
- After it has been determined that each appliance remaining connected to the common venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas-burning appliance to their previous condition of use.
- Any improper operation of the common venting system should be corrected so that the installation conforms to the National Fuel Gas Code, ANSI Z223.1 and/or CAN/CGA B149, Installation Codes. When resizing any portion of the common venting system, the common venting system should be resized to approach the minimum size as determined using the appropriate tables in Part 11 of the National Fuel Gas Code, ANSI Z223.1 and /or CAN/CGA B149, Installation Codes.

Heat exchanger surfaces and vent piping should be checked every six months for deterioration and carbon deposits. Remove all soot or other obstructions from the chimney and flue, which might impede draft action. Replace any damaged or deteriorated parts of the venting system.



A qualified service technician should follow this procedure when inspecting and cleaning the heat exchanger and vent pipe.

1. Turn off electrical power and main manual gas shut-off and allow appliance to cool down.
2. Remove the vent pipe running to the chimney and check heat exchanger, vent and chimney for obstruction and clean as necessary.
3. Remove burner from appliance and carefully clean as required. Never brush or wipe the knitted metal fiber surface, use a garden hose and wash instead.  
**Caution: Never use pressure washer to clean the burner.**
4. Use pressure wash to clean heat exchanger if necessary.
5. Reinstall parts removed in steps 2 and 3. Be sure that vent pipe has proper pitch and is properly sealed. Replace any damaged gasket. Note that the burner is supplied with two gaskets; a high temperature ceramic paper gasket under the burner flange and a stamped silicon gasket between the burner flange and fan flange. Tighten fan flange mounting nuts to 20 ft-lb.
6. Restore electrical power and gas supply to appliance.
7. Place appliance in operation using lighting instructions provided.
8. Confirm proper operation of all safety devices
9. Check for gas leaks and proper vent operation.

**NOTE:**

Experience has shown that improper installation or system design, rather than faulty equipment, is the cause of most operating problems

**1.9 BOILER ROOM OPERATING CONDITION**

- Due to low jacket losses from the appliance, temperatures in a typical boiler room may drop significantly; supplemental heat is required to maintain ambient temperature at acceptable levels.
- Camus DynaForce boilers and water heaters are approved at 90% efficiency which require that the equipment to be vented as a Category II or IV condensing appliance.


**1.10 CLEARANCE FROM COMBUSTIBLE MATERIAL**

This appliance is suitable for alcove (a closet without a door) installation with minimum clearances to combustibles as follows:

**Table 1: Clearances from Combustibles**

<b>Clearances from Combustibles</b>	
TOP:	12"
SIDES:	12"
REAR:	12"
VENT:	6"

**Figure 4: Clearance from Combustibles**



When placing the appliance be aware that a minimum clearance of 24" (60cm) must be provided at the front to allow easy access to the primary heat exchanger.

**NOTE:** Clearances from combustible construction are noted on the appliance rating plate

Maintain minimum specified clearances for adequate operation. All installations must allow sufficient space for servicing the vent connections, water pipe connections, circulating pump, bypass piping and other auxiliary equipment, as well as the appliance

**Table 2: Service Clearances**


Service Clearances					
Model Numbers	Service Clearance, Inches (cm)				
	Top	Right Side	Left Side	Back	Front
300	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
350	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
400	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
500	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
600	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
800	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
1000	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
1200	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
1400	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
1600	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
1800	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
2000	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
2500	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
3000	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
3500	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
4000	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
4500	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)
5000	24" (60cm)	12" (30cm)	12" (30cm)	*	24" (60cm)

\* Allow adequate space for the venting in addition to 6" clearance to combustibles.

### 1.11 INSTALLATION PROCEDURE AND LOCATION OF UNIT

Install this appliance in a clean, dry location with adequate air supply and close to a good vent connection.

- Do not locate this appliance in an area where it will be subject to freezing unless precautions are taken. Radiant losses from the DynaForce are minimal and should not be relied on to keep the appliance room warm. If the appliance is installed in a cold room and/or on a cold floor, isolating the appliance from the cold floor and heating the room is recommended.
- The appliance should be located close to a floor drain in an area where leakage from the appliance or connections will not result in damage to the adjacent area or to lower floors in the structure, it is recommended that a suitable drain pan, adequately drained, be installed under the unit. Under no circumstances is the manufacturer to be held responsible for water damage in connection with this unit, or any of its components. If the appliance is installed above the level of the building's radiation system, a low water cut-off device must be installed above the heat exchanger inlet/outlet connections. Some local codes require the installation of a low water cut-off on all systems
- When placing the appliance be aware that a minimum clearance of 24" must be provided at the front to allow easy access to the primary heat exchanger.
- The appliance must be installed so that the ignition system components are protected from water (dripping, spraying, etc.) during appliance operation and service (circulator replacement, control replacement, etc.)
- Appliances located in a residential garage and in adjacent spaces that open to the garage and are not part of the living space of a dwelling unit must be installed so that all burners and burner ignition devices have a minimum clearance of not less than 18" (46cm) above the floor. The appliance must be located or protected so that it is not subject to physical damage by a moving vehicle.
- **DO NOT** install this appliance in any location where gasoline or flammable vapors are likely to be present.
- Appliance must be installed on a level floor. Maintain required clearances from combustible surfaces.
- The appliance designed for indoor installation (Indoor Models) must be installed indoors where it is protected from exposure to wind, rain and weather.
- The appliance designed for outdoor installation (Outdoor Models) must be installed outdoors. For outdoor installations, always consider the use of a shelter such as a garden shed in lieu of direct exposure of the appliance to the elements. The additional protection afforded by the shelter will help to minimize nuisance problems with electrical connections and will allow easier servicing of the appliance under severe weather conditions.



**Table 3: Appliance Dimensions and Specifications**

**DynaForce Dimensions**

Model	Dim. "A" (in.)	Dim. "B" (in.)	Dim. "C" (in.)	Dim. "D" (in.)	Dim. "E" (in.)	Dim. "F" (in.)	Dim. "G" (in.)	Dim. "H" (in.)	Dim. "I" (in.)	Dim. "J" (in.)	Dim. "K" (in.)	Ø Dim. "L" (in.) Air Inlet	Ø Dim. "V" (in.) Vent CAT. IV	Ø Dim. "V" (in.) Vent CAT. II	Ø Dim. "W" (in.) Water	Ø Dim. "X" (in.) Gas	Weight (lbs.)
0300	25	27	34	12 1/4	32 1/2	8 1/8	27	2 5/8	3 1/2	9 3/4	5 1/2	4	4	4	1 1/2	1	190
0350	25	27	35	12 1/4	33 1/2	8 1/8	28	2 5/8	3 1/2	9 3/4	5 1/2	4	4	5	1 1/2	1	220
0400	25	27	40	13 1/4	36	9 1/2	33	2 5/8	3 1/2	9 3/4	5 1/2	5	4	5	1 1/2	1	250
0500	25	27	43	14 1/4	39	10 1/2	36	2 5/8	3 1/2	9 3/4	5 1/2	5	5	5	1 1/2	1	315
0600	25	27	46	15 1/4	42 1/2	10 1/2	39	2 5/8	3 1/2	9 3/4	5 1/2	6	5	6	1 1/2	1	375
0800	25	27	54	17 1/4	48 1/2	11 1/2	47	2 5/8	4	9 3/4	5 1/2	6	6	6	2	1	400
1000	25	27	60	17 1/4	54 1/2	11 1/2	53	2 5/8	12 1/2	9 3/4	5 1/2	8	6	7	2	1	485
1200	29 1/2	34	70	18	59 1/2	12	58 1/2	1 7/8	14 3/4	10 1/2	8 1/2	8	7	8	2 1/2	1 1/4	582
1400	29 1/2	34	73	20	65 1/2	13	60 1/2	1 7/8	14 3/4	10 1/2	8 1/2	8	7	8	2 1/2	1 1/4	679
1600	29 1/2	34	73	20	65 1/2	13	60 1/2	1 7/8	14 3/4	10 1/2	8 1/2	10	7	9	2 1/2	1 1/4	776
1800	29 1/2	34	73	20	65 1/2	13	60 1/2	1 7/8	14 3/4	10 1/2	8 1/2	10	8	9	2 1/2	1 1/4	700
2000	29 1/2	34	78	22	67 3/4	14	65 1/2	1 7/8	14 3/4	10 1/2	8 1/2	10	8	10	3	1 1/2	800
2500	29 1/2	34	88	24 1/2	79 1/2	15	73 1/2	1 7/8	14 3/4	10 1/2	8 1/2	12	9	10	3	1 1/2	825
3000	29 1/2	34	90	24 1/2	81 1/2	15	75 1/2	1 7/8	14 3/4	10 1/2	8 1/2	12	9	10	3	1 1/2	920
3500	29 1/2	34	94	25 1/2	84 1/2	15 1/2	79 1/2	2 1/4	14 3/4	10 1/2	8 1/2	12	10	12	3	2	1050
4000	29 1/2	34	94	25 1/2	84 1/2	15 1/2	79 1/2	2 1/4	14 3/4	10 1/2	11	14	10	12	3	2	1140
4500	29 1/2	34	97	27 1/2	87 1/2	16 1/2	82 1/2	3 1/2	14 3/4	10 1/2	11	14	12	12	4	2 1/2	1250
5000	35 3/4	39 1/4	102	27 1/2	91	16 1/2	86	3 1/2	17 7/8	12 3/8	11	14	12	12	4	2 1/2	1350

## PART 2 VENTING

### **⚠ DANGER**


It is extremely important to follow these venting instructions carefully. Failure to do so can cause severe personal injury, death or substantial property damage.

### **⚠ DANGER**

Foam Core Pipe, PVC, CPVC are not to be used in any part of the venting system.

### 1.1 GENERAL VENTING GUIDE

Figure 5: Venting Configurations



The DynaForce is a category II or IV condensing appliance, 94% efficient unit.

- The DynaForce may be vented with manufactured prefabricated UL/ULC listed vents of AL29-4C or 316L stainless steel or with plastic vent certified to UL/ ULC S636, such as, IPEX System 636 CPVC or IPEX System 636 PVC or as permitted by local jurisdictions.
- The DynaForce boiler must be vented and supplied with combustion and ventilation air as described in this section. Ensure that the venting and combustion air supply complies with these instructions regarding the vent system, air system, and combustion air quality.
- Vent installations for connection to gas vents or chimneys must be in accordance with Part 7, "Venting of Equipment," of the latest edition of the National Fuel Gas Code, ANSI Z223.1, in Canada, the latest edition of CAN/CGA Standard B149 Installation Codes for Gas Burning Appliances and Equipment or applicable provisions of the local building codes.
- The distance of the vent terminal from adjacent buildings, windows that open and building openings MUST comply with the latest edition of the National Fuel Gas Code, ANSI Z223.1, in Canada, the latest edition of CAN/CGA Standard B149 Installation Code for Gas Burning Appliances and Equipment.
- Vent connection is made directly to the flue outlet opening on the back of the unit. The connection from the appliance vent to the stack must be made as direct as possible.
- Appliances for outdoor installation are intended to vent using a listed vent cap. For indoor installations venting must be in accordance with Part 7, Venting of Equipment, of the National Fuel Gas Code, ANSI Z223.1, or Section 7, Venting of Equipment and Air Supply for Appliances, of the CAN/CGA B149, Installation Codes, or applicable provisions of the local building codes.
- Vent connectors serving appliances vented by natural draft shall not be connected into any portion of mechanical draft systems operating under positive pressure.

- Horizontal runs of vent pipe shall be securely supported (approximately every 4 feet) to prevent sagging and maintain a minimum upward slope of ¼" per foot from the appliance to the vent terminal.
- The weight of the venting system must not rest on the unit. Adequate support of the venting system must be provided in compliance with local codes and other applicable codes.
- All connections should be secured and sealed per the vent manufacturers specifications. When a Positive vent system is disconnected for any reason, the flue must be reassembled and resealed according to the vent manufacturer's instructions.
- Do not use an existing chimney as a raceway if another appliance or fireplace is vented through the chimney.

### 2.1.3 CATEGORY II AND CATEGORY IV VENTING

A Category II venting system operates with a negative pressure in the vent.

The Category IV venting system operates with positive pressure generated by the internal combustion air fan which operates the combustion process and also exhausts the flue products from the building.

- The Category II flues from multiple appliances can be combined into a common vent, this special venting system must be engineered by venting manufacturer and to be approved by local authority.
- The Category IV flues from multiple appliances **CAN NOT** be combined into a common vent.
- The Category IV flue must be a dedicated stack.
- The Category IV Flue appliance must have all vent joints and seams sealed gas-tight
- The flue products in the vent system will be cooled below their dew point and form condensate in the flue and must use AL29-4C material.
- The flue from a Category II and IV vent system must have a condensate drain with provisions to properly collect and dispose of any condensate that may occur.

### 2.1.4 VENTING GUIDELINES FOR CATEGORY II AND/OR IV VENTING

- The installed length of the Positive pressure flue from the appliance to the point of termination, outside of the building, **must not exceed a maximum of 100 equivalent feet (30.5M) in length.** Depending on diameter and centerline radius subtract from 7 to 19 feet per 90° elbow using published data. Subtract h alf this value for each 45° elbow.
- The flue may terminate either vertically at the roof top or horizontally on a THRUWALL. See the information about the specific vent termination location for recommended location and clearances.

### 2.1.5 APPROVED VENTING MATERIALS

#### **Exhaust Vent for Use for DynaForce Category II or IV Installations**

- 1 Manufactured prefabricated UL/ ULC listed vent of AL29-4C or equivalent, Single or Double Wall.
- 2 316L stainless steel is limited to use in applications where there is no possibility of contaminants in the air such as refrigerants, chlorine etc.
- 3 "BH" type.
- 4 PVC and CPVC Schedule 40 or 80 approved to ULC S636 up to 8" diameter

- 5 PVC-DWV approved to comply with ANSI/ASTM D2665 up to 8" diameter (US Jurisdictions ONLY when permitted)
- 6 PVC Schedule 40 approved to comply with ANSI/ASTM D1785 up to 8" diameter (US Jurisdictions ONLY when permitted)
- 7 CPVC Schedule 40 approved to comply with ANSI/ASTM F441 up to 8" diameter. (US Jurisdictions ONLY when permitted)

**Table 4: Maximum Flue Temperature for Various Vent Materials**

Vent Material	Maximum Flue Temperature [°F]
PVC	149
CPVC	194
AL29-4C	300+, limited only by rating of seals
316L Stainless Steel	300+, limited only by rating of seals

### Vent material selection

When selecting vent material take into consideration that appliances installed near a corrosive or potentially corrosive air supply must be isolated from it or they will suffer damage to the appliance and the venting system.

The corrosion resistance of AL29-4C is typically higher than that of 316L. Always choose the venting system which best satisfies the requirements of the application.

***This recommendation does not supersede local codes or the provision of the B149 in Canada or the National Fuel Gas Code in the United States***

### Intake Air (Supply Air, or Fresh Air) Piping

- 1 PVC Non Foam Core Pipe.
- 2 CPVC (Chlorinated Polyvinyl Chloride).
- 3 ABS (Acrylonitrile-Butadiene-Styrene).
- 4 Single wall, galvanized
- 5 Single wall, Stainless Steel
- 6 Single wall, Aluminium

Single wall vent pipes are to be insulated 5 feet from wall toward the interior of the building to minimize external sweating.

### **2.1.6 VENT TERMINATION CLEARANCES**

- Do not terminate the vent in a window well, stairwell, alcove, courtyard or other recessed area. The vent cannot terminate below grade. The bottom of the vent terminal shall be located at least 12 inches (30cm) above grade and above normal snow levels. In all cases the appliance shall be installed in accordance with local codes.
- The vent outlet MUST NOT terminate below a forced air inlet at any distance.
- The vent cannot terminate below grade. Position the vent termination where vapours will not damage walls or plants or may otherwise be objectionable.
- The vent terminal shall not be installed closer than 3 feet (1 m) from an inside corner of an L-shaped structure, window well, stairwell, alcove, courtyard or other recessed area as wind eddies could affect boiler performance or cause recirculation.

- DO NOT terminate closer than 4 feet (1.25m) horizontally and vertically from any electric meter, gas meter, regulator, relief valve, or other equipment. In all cases local codes take precedence
- Position terminations so they are not likely to be damaged by foreign objects, or exposed to a build-up of debris.
- The vent piping must terminate in an elbow pointed outward or away from the air inlet.
- To avoid a blocked flue condition, keep the vent cap/terminal clear of snow, ice, leaves, debris, etc.
- Flue gases from this appliance may contain large amounts of water vapour that will form a white plume in winter. Plume could obstruct a window view.
- Flue gas condensate can freeze on exterior walls or on the vent cap. Frozen condensate on the vent cap can result in a blocked flue condition. Some discoloration to exterior building surfaces can be expected. Adjacent brick or masonry surfaces should be protected with a rust resistant sheet metal plate.


### **2.1.7 INLET CAP FOR ROOFTOP TERMINATION**

The air inlet cap consists of two 90° elbows installed at the point of termination for the air inlet pipe. The first 90° elbow is installed on the rooftop at the highest vertical point of the air inlet pipe and turned horizontal; the second 90° elbow is screened and is installed on the horizontal outlet of the first elbow and turned down. A 90° elbow and a 90° street elbow may be used to make this assembly. If a straight piece of pipe is used between the two elbows, it should not exceed 6" (150mm) in length.

### **2.1.8 LOCATION OF A ROOFTOP AIR INLET AND VENT CAPS**

- The point of termination for the combustion air inlet cap MUST be at least 3 feet (0.91M) below the point of flue gas termination (vent cap) if it is located within a 5 foot (1.5M) radius of the flue outlet. Use care to ensure that the 90° elbow assembly is properly installed on the air inlet pipe.
- The termination point of the combustion air inlet cap must be installed at least 3 feet (0.91M) above the rooftop and above normal snow levels.
- The vent cap assembly MUST be listed by nationally recognized agencies.
- The combustion air cap and vent cap MUST be located on the same roof top surface and in the same pressure zone
- Combustion air supplied from outdoors must be free of contaminants. To prevent recirculation of flue products in to the combustion air inlet, follow all instructions in this section.
- Incorrect installation and/or location of the air inlet cap can allow flue products to be drawn back into the appliance. This can result in incomplete combustion and potentially hazardous levels of carbon monoxide in the flue products. This will cause operational problems with the appliance and if left uncorrected, will lead to conditions that can cause personal injury or death.


**Figure 6: Vertical Direct Venting Configuration**



**2.1.9 AIR INLET DAMPER**

In warmer climates, during cold weather, the use of ducted outdoor air may result in the formation of condensation on the interior panels of the combustion chamber. It may be possible for this condensation to accumulate and drip out of the appliance jacket. If this is not acceptable, it is advisable to install a motorized combustion air damper in the combustion air duct interlocked with the appliance’s start circuit. In cold climates it is essential to provide a motorized air inlet damper to control the supply of combustion air and prevent nuisance condensation.

**Figure 6: Air Inlet Damper Connection Inside J-Box**



**2.1.10 MASONRY CHIMNEY INSULATIONS**

Always follow local codes when venting this appliance into a masonry chimney. A standard masonry chimney must NOT be used to vent the products of combustion from the flue, positive or negative pressure appliance (Category II or IV). If a masonry chimney is to be used, the chimney MUST use a sealed, metallic, corrosion resistant liner system to vent flue products from this high efficiency appliance. Sealed, metallic, corrosion resistant liner systems (AL29-4C or equivalent, single wall or double-wall, or flexible or rigid metallic liners) must be rated for use with a high efficiency condensing, positive pressure vent system. Corrosion resistant chimney liner systems are typically made from a high grade of corrosion resistant stainless steel such as AL29-4C or equivalent. The corrosion resistant liner must be properly sized and fully sealed throughout the entire length. If the flue is contained within the masonry chimney both the top and the bottom of the masonry chimney must be capped and sealed to provide a dead air space around the sealed corrosion resistant metallic liner.

**Consult with local code officials to determine code requirements or the advisability of using a masonry chimney with a sealed corrosion resistant liner system.**

**2.1.11 VERTICAL VENTING TERMINATION**

- Follow Category II or IV vent termination and all General instructions.
- The vent terminal should be vertical and exhaust outside the building at least 2 feet (0.61M) above the highest point of the roof within a 10 foot (3.05M) radius of the termination.
- The vertical termination must be a minimum of 3 feet (0.91M) above the point of exit.
- A vertical termination less than 10 feet (3.05M) from a parapet wall must be a minimum of 2 feet (0.61M) higher than the parapet wall.

**2.1.12 COMBINED COMBUSTION AIR INLET**

The air inlet pipes from multiple appliances can be combined to a single common connection if the common air inlet pipe has a cross sectional area equal to or larger than the total area of all air inlet pipes connected to the common air inlet pipe.

Equivalent pipe diameter = Sq Root [(d<sub>1</sub>)<sup>2</sup> + (d<sub>2</sub>)<sup>2</sup> + (d<sub>3</sub>)<sup>2</sup> + (d<sub>4</sub>)<sup>2</sup> + ..... + (d<sub>n</sub>)<sup>2</sup>], d, pipe diameter


❖ Example: What is equivalent pipe diameter of three air inlet pipes, 8" (20.3 cm), 10" (25.4 cm) and 12" (30.5 cm)

Equivalent pipe diameter = Sq Root [(8)<sup>2</sup> + (10)<sup>2</sup> + (12)<sup>2</sup>] = Sq Root (308) = 17.5", Select 18" (82.8 cm) diameter pipe or larger.

The air inlet point for multiple boiler air inlets must be provided with an exterior opening which has a free area equal to or greater than the total area of all air inlet pipes connected to the common air inlet. This exterior opening for combustion air must connect directly to the outdoors. The total length of the combined air inlet pipe must not exceed a maximum of 100" (30.5M) equivalent feet. You must deduct the restriction in area provided by any screens, grills or louvers installed in the common air inlet point. Screens, grills or louvers installed in the common air inlet can reduce the free area of the opening from 25% to 75% based on the materials used. Calculate and compensate accordingly for the restriction.

**2.1.13 DRAIN TEE**

**Figure 7: Drain "T" and Neutralizer Cartridge Installation**



A drain tee **MUST** be installed in the vent pipe to collect and dispose of any condensate that may occur in the vent system. The drain tee should be installed at the point where the flue turns vertical for a roof top termination or as one of the first fittings in a horizontal flue that will terminate on a THRUWALL. Ensure that horizontal portions of the vent are properly sloped away from the appliance to allow condensate to be evacuated at the drain tee. Plastic drain tubing, sized per the vent manufacturer's instructions, shall be provided as a drain line from the tee. The drain tubing must have a trap provided by a 4" (10cm)-diameter circular trap loop in the drain tubing. Prime the trap loop by pouring a small quantity of water into the drain hose before assembly to the vent. Secure the trap loop in position with nylon ties. Use caution not to collapse or restrict the condensate drain line with the nylon wire ties. The condensate drain must be routed to the condensate neutralization system or a suitable drain for disposal of condensate that may occur in the vent system.

Ensure that the drain from the condensate tee is not exposed to freezing temperature.

## 2.2 CONVENTIONAL VENTING (INDOOR) INSTALLATIONS

- The DynaForce is a category II appliance and is approved for venting into a common Chimney. On single appliance installations with dedicated chimney, if drafts are excessive (above negative 0.15 Inches W.C.), we recommend a single acting barometric damper.
- A qualified professional using a proven vent-sizing program with input of accurate operating parameters must properly do sizing of the venting system. In applications where flue gas temperatures are lower than can support a Category II with conventional negative draft, it will be determined at the venting design stage that a positive pressure will be developed in the vent. It will then be necessary to either provide separate vents as for Category IV, pressurize the room or to provide an extractor at the chimney outlet interlocked with the appliance operating circuit in order to maintain a negative draft in the chimney and allow common venting.
- Approval of the installation will be at the discretion of authorities having jurisdiction.

### • IN GENERAL

- The operation of exhaust fans, compressors, air handling units etc. can rob air from the room, creating a negative pressure condition leading to reversal of the natural draft action of the venting system. Under these circumstances an engineered air supply is necessary.
- If the appliance is to be installed near a corrosive or potentially corrosive air supply, the appliance must be isolated from it and outside air should be supplied as per code.
- Potentially corrosive atmospheres will result from exposure to permanent wave solution, chlorinated waxes and cleaners, chlorine, water softening chemicals, carbon tetrachloride, halogen based refrigerants, Freon cleaning solvents, hydrochloric acid, cements and glues, masonry washing materials, antistatic fabric softeners, dry cleaning solvents, degreasing liquids, printing inks, paint removers, etc.

- The equipment room **MUST** be provided with properly sized openings to assure adequate combustion air and proper ventilation when the unit is installed with a proper venting system.

### 2.2.1 AIR REQUIRED FOR COMBUSTION AND VENTILATION

If air is taken directly from outside the building with no duct, provide two permanent openings:

- a) Net free area for combustion air opening shall be in accordance with all applicable codes. In the absence of such codes provide combustion air opening with a minimum free area of one square inch per 7000 Btuh input (5.5 cm per kW) up to 1,000,000 Btuh and one square inch per 14,000 Btuh in excess of 1,000,000 Btuh. This opening must be ducted no higher than 18" nor less than 6" above the floor. Provide a ventilation air opening located as high as practical in the room sized no less than 10% of the air supply opening.
- b) Provision for combustion and ventilation must be in accordance with :
  - Applicable sections of The National Fuel Gas code ANSI Z223.1
  - Applicable sections of CAN/CGA B149 installation Codes
  - Applicable provisions of the local building codes.

#### NOTE

Outside air openings shall directly communicate with the outdoors.

#### CAUTION

Under no circumstances should the mechanical room ever be under a negative pressure. Particular care should be taken where exhaust fan, attic fans, clothes dryers, compressors, air handling units, etc., may take away air from the unit.

### 2.2.2 EXHAUST FANS

Any fan or equipment which exhausts air from the equipment room may deplete the combustion air supply and/or cause a downdraft in the venting system through a barometric damper if installed. Spillage of flue products from the venting system into an occupied living space can cause a very hazardous condition that must be immediately corrected.

## 2.3 OUTDOOR VENTING

The DynaForce windproof cabinet protects the unit from weather, when fitted with the factory supplied air intake and UL approved vent cap (93-0298), it will be self-venting and suitable for outdoor installation.

1. Outdoor models must be installed outdoors and must use the Air Intake and Vent Cap supplied by Camus Hydronics.
2. Periodically check to ensure that air intake and vent cap are not obstructed.
3. Locate appliance at least 3 feet away from any overhang.
4. Locate appliance at least ten feet from building air intake.
5. Avoid installation in areas where runoff from adjacent building can spill onto appliance.

For outdoor installations, always consider the use of a shelter such as a garden shed in lieu of direct exposure of the appliance to the elements. The additional protection afforded by the shelter will help to minimize nuisance problems with electrical connections and will allow easier servicing of the appliance under severe weather conditions.

## **2.4 THRUWALL VENTING**

When fitted with the factory supplied vent terminal, the DynaForce can vent up to 100 equivalent feet. Elbows can range from 7 to 19 feet in equivalent length depending on centreline radius. Refer to table 5 for vent sizes.

Appliances may be installed with either a horizontal sidewall vent or vertical roof top vent. Terminals differ with each application. Horizontal lengths over 5 feet must be installed using corrosion resistant stainless steel. Use single wall vent and seal all joints or use pressure rated double wall vent.

When using single wall vent, all vent connector seams and joints must be sealed with pressure sensitive aluminium tape or silicone sealant as specified by the vent manufacturer. Aluminium tape must meet the provisions of SMACNA AFTS-100-73 Standard.

Periodically check to ensure that the vent terminal is unobstructed.

This venting system uses the appliance's internal combustion air fan to force the flue products out horizontally.

The DynaForce fan generates a positive pressure in the flue. Combustion air is drawn from the equipment room. The THRUWALL terminations are available from the factory. Refer to local codes for proper installation and location of vent terminals.

### **2.4.1 THRUWALL VENT TERMINAL & THRUWALL INTAKE AIR TERMINAL**

- The THRUWALL vent terminal kit includes the wall penetration assembly and the discharge screen assembly.
- The opening through the wall for installation of the THRUWALL vent terminal must provide an air space clearance of 1 inch (2.5cm) around the flue pipe. The diameter of the opening for installation of the THRUWALL vent terminal will be 2 inches (5cm) larger than the nominal diameter of the installed vent pipe to the THRUWALL vent cap. The diameter of the opening for the air inlet cap will be the same as the nominal size of the pipe.
- Install the proper vent pipe to the vent terminal (provided by Camus Hydronics).
- Follow all requirements in the General Venting sections for venting flue products to the outdoors.

### **2.4.2 LOCATION OF A THRUWALL VENT TERMINATION**

- The vent terminal shall terminate at least 3 feet (1M) above any forced air inlet within 10 feet (3M) horizontally.
- The vent terminal **MUST NOT** terminate below a forced air intake at any distance.
- Do not terminate the vent in a window well, stairwell,

alcove, courtyard or other recessed area. The vent cannot terminate below grade.

- The vent shall not terminate less than 7 feet above a public walkway due to the normal formation of water vapour in the combustion process.
- The vent system shall terminate at least 3 foot (1M) above grade, above normal snow levels and at least 7 feet (2.15M) above grade when located adjacent to public walkways.
- The vent terminal shall not be installed closer than 3 feet (1M) from an inside corner of an L-shaped structure.
- The vent terminal should have a minimum clearance of 4 feet (1.25M) horizontally from and in no case above or below, unless a 4-foot (1.25 m) horizontal distance is maintained from electric meters, gas meters, regulators and relief equipment. In all cases local codes take precedence.
- Flue gas condensate can freeze on exterior walls or on the vent terminal. Frozen condensate on the vent cap can result in a blocked flue condition. Some discoloration to exterior building surfaces can be expected. Adjacent brick or masonry surfaces should be protected with a rust resistant sheet metal plate.

### **2.4.3 LOCATION OF A "THRUWALL" AIR INLET TERMINAL**

- The termination point of the THRUWALL air inlet must be installed a minimum of 3 feet above ground level and above normal levels of snow accumulation.
- The point of termination for the THRUWALL combustion air inlet cap **MUST** be located a minimum of 3 feet (1M) horizontally and 12 inches (0.30M) below the point of flue gas termination (vent cap) if it is located within a 10 foot (3M) radius of the flue outlet.

### **2.4.4 LENGTH OF AIR INLET PIPE**

The maximum total length of the THRUWALL or vertical roof top combustion air inlet pipe as installed from the appliance to the air inlet terminal must not exceed (100 ft) equivalent feet (30.5m) in length. Subtract 7 (2.13 m) to 19 feet (5.8 m) of equivalent length depending on centreline radius for each 90° elbow installed in the air inlet pipe system. Pressure drop in 45° elbow will be half as much.



## PART 3 GAS CONNECTION

Verify that the appliance is supplied with the type gas specified on the rating plate. Consult factory for installations at high altitude.

### 3.1 GAS CONNECTION

- Safe operation of unit requires properly sized gas supply piping. See gas line sizing data.
- Gas pipe size may be larger than appliance connection.
- Installation of a union at the appliance gas line connection is required for ease of service and removal of the gas train.
- Install a manual main gas shutoff valve, outside of the appliance gas connection as require by local codes.
- A trap (drip leg) MUST be provided in the inlet gas connection to the appliance.
- Optional gas controls may require routing of bleeds and vents to the atmosphere, outside the building when required by local codes.

**Table 5: Recommended Gas Pipe Size**

Single Appliance Installation

(For distance from natural gas meter or propane second stage regulator)

Input Btu/Hr, x1000	0-100 FT		101-200 FT		201-300 FT	
	NAT.	L.P.	NAT.	L.P.	NAT.	L.P.
300	1 ¼"	1"	1 ½"	1 ¼"	1 ½"	1 ¼"
400	1 ¼"	1"	1 ½"	1 ¼"	2"	1 ½"
500	1 ½"	1 ¼"	2"	1 ½"	2"	1 ½"
600	1 ½"	1 ¼"	2"	1 ½"	2"	1 ½"
800	2"	1 ½"	2"	1 ½"	2 ½"	2"
1000	2"	1 ½"	2"	1 ½"	2 ½"	2"
1200	2"	1 ½"	2 ½"	2"	2 ½"	2"
1400	2 ½"	2"	2 ½"	2"	3"	2 ½"
1600	2 ½"	2"	3"	2 ½"	3"	2 ½"
1800	2 ½"	2"	3"	2 ½"	3"	2 ½"
2000	2 ½"	2"	3"	2 ½"	3"	2 ½"
2500	3"	2 ½"	3"	2 ½"	3 1/2"	3"
3000	3"	2 ½"	3"	2 ½"	3 1/2"	3"
3500	3"	2 ½"	3 ½"	3"	4"	3 ½"
4000	3 ½"	3"	4"	3 ½"	4"	3 ½"
4500	3 ½"	3"	4"	3 ½"	4"	3 ½"
5000	4"	3 ½"	4"	3 ½"	5"	4"

### 3.2 GAS PIPING

All gas connections must be made with pipe joint compound resistant to the action of liquefied petroleum and natural gas. All piping must comply with local codes and ordinances.

### 3.3 INSTALL PIPING

- The gas line should sufficient to handle the total installed capacity. Verify pipe size with gas supplier.
- Use new, properly threaded black iron pipe free from burrs. Avoid flexible gas connections. Internal diameter of flexible gas lines may not provide appliance with proper volume of gas.
- Install a manual main gas shutoff valve at the appliance gas inlet, outside of the appliance and before the gas valve. Install a joint union at the appliance gas line connection for ease of service and removal of the gas train.
- Run pipe to the Appliance gas inlet.
- Install a sediment trap in the supply line to the Appliance gas inlet.
- Apply a moderate amount of good quality pipe compound.
- For LP gas, consult your LP gas supplier for expert installation.

The appliance and its individual gas shut-off valve must be disconnected from the supply piping when pressure testing the gas supply piping at pressures above ½ PSI

**Table 6: Gas Pressures at Inlet to Appliance**

	PROPANE	NATURAL GAS
Minimum (inches W.C.)	11	3
Maximum (inches W.C.)	11	14

The gas supply line must be of adequate size to prevent undue pressure drop and must never be smaller than the size of the connection on the appliance. Sizing based on Table 7 is recommended.

Before operating the appliance, the complete gas train and all connections must be tested using soap solution.

Verify that the appliance is supplied with the type gas specified on the rating plate. Heating values of local natural gas are to be between 950 and 1010 Btu/ft<sup>3</sup>. Consult factory if heating values are outside this range or if a gas with a mixture of constituents is being used.


### 3.4 AIR/GAS RATIO VALVE

The main gas valve supplying gas to the burner on this appliance utilizes a servo pressure regulator providing a slow opening, fast closing safety shut off and air/gas ratio control for the gas combustion process. The valve is a 1:1 negative pressure gas valve. The valve performs the functions of a pressure regulator, safety shutoff, and air/gas ratio control. Full closing of the valve seat occurs in less than 0.8 seconds when the valve is de-energized. Operation of the gas valve in combination with the combustion air fan allows the burner input rate to vary from 20% to 100% based on temperature demand. The inlet gas supply pressure must be maintained within the specified minimum and maximum pressures.


The air/gas ratio is preset at the factory and adjustment is not usually required if gas supply pressure is maintained within the specified range.

There are no serviceable parts on the air/gas ratio valve control.

**Figure 8: DR300 – 400 1:1 Air/Gas Ratio Control Valve**



**Figure 9: DR500 – 1800 1:1 Air Gas Ratio Control Valve**




main gas valve supplying gas to the burner on this appliance utilizes a pressure regulating electro hydraulic actuator providing a slow opening, fast closing safety shut off and air/gas ratio control for the gas combustion process. This gas valve controls the pressure difference across the restriction in the gas supply line as a function of the pressure difference across the combustion air supply to the burner. The actuator maintains a constant air to gas ratio as the volume of air changes based on the operation of the combustion air fan. The valve is a 1:1 differential pressure air/gas ratio controller. The valve generates the same pressure difference on the gas side as it senses on the air side. The valve performs the functions of pressure regulator, safety shutoff, and air/gas ratio control. Slow opening and safety shutoff is accomplished by operation of an electro hydraulic cylinder. Full closing of the valve seat occurs in less than 0.8 seconds when the valve is de-energized. A visual stroke position indicator is provided on the valve assembly to indicate the position of the valve seat. Operation of the gas valve in combination with the combustion air fan allows the burner input rate to vary from 20% to 100% based on temperature demand. The inlet gas supply pressure must be maintained within the specified minimum and maximum pressures. A reduction of up to 30% is permitted in the inlet gas pressure between light off and full fire conditions.

The manifold differential pressure is preset at the factory and adjustment is not usually required if gas supply pressure is maintained within the specified range. If the manifold differential pressure is to be measured, follow the "Gas Manifold Pressure Measurement Procedure" for proper measurement.

There are no serviceable parts on the ratio gas valve actuator

**Figure 10: DR2000-5000 1:1 Air/Gas Ratio Control Valve**



### 3.4 DIFFERENTIAL AIR PRESSURE (DR2000 – DR5000)

- The DynaForce 2000 – 5000 operates on the principle of differential pressures. Operation of the fan generates a signal which is matched on the gas side by the 1 to 1 air/gas ratio control valve.
- The differential air pressure measurement is made between the high and low pressure taps across the fan discharge and the flue vent. All differential air pressures are noted at full firing rate. There are two pressure taps at the fan discharge and care must be taken to tee into the correct line. The correct line may be identified by tracing it back to the ratio control valve where the identification of the tapping is stamped into the die cast actuator.
- The differential gas pressure measurement is made between the high and low pressure taps across the in-line metering gas orifice. Check this value to confirm that it matches the differential air pressure while the appliance is firing.
- The controls on this appliance may fire the burner from 20% up to 100 % of rated input.
- Differential manifold gas pressure will be reduced as burner input is reduced.
- All reference gas pressure measurements must be made at 100% of rated burner input.
- The differential gas manifold pressure is pre-set at the factory through the ratio gas valve. Adjustment of manifold pressure is not normally required for proper operation. In the field it may be necessary to adjust the low fire adjustment screw located on the ratio control valve actuator in order to achieve acceptable light off under soft start field conditions.
- **Always check settings posted on boiler test label.**

### 3.5 GAS MANIFOLD DIFFERENTIAL PRESSURE ADJUSTMENT (DR2000 – DR5000)

Tampering with gas valve adjustments after startup and commissioning will void the warranty on the gas valve assembly and the burner.

The appliance's manifold gas pressure **IS NOT** field adjustable after startup and commissioning. The gas valve pressure ratios have been factory set with an internal bias adjustment to ensure a 1:1 air/gas ratio on operation. Tampering with this adjustment will void the warranty on the gas valve assembly and the burner. An appliance supplied with a properly sized gas line, properly sized meter and a minimum gas supply pressure (See Table 7 for minimum allowable inlet gas supply pressure) while firing at full rate

will ensure full burner input. The manifold pressure supplied to the burner is a differential pressure. This pressure is the result of the difference in two gas pressure measurements. A differential manifold gas pressure measurement should not be made until you have measured the gas supply pressure. Gas supply pressure must be at least at minimum allowed with all appliances on the gas line firing at full rate before a manifold pressure measurement is made. Use the following procedure to check gas supply pressure with a manometer connected to the inlet pressure tap on the gas line connection at the rear of the appliance.

### 3.6 CHECKING GAS SUPPLY PRESSURE

- Turn the main power switch to “OFF” position.
- Shut off gas supply at the manual gas cock in the gas piping to the appliance. If fuel supply is LP gas, shut off gas supply at the tank.
- Remove the 1/8" hex plug from the gas pressure test port located on the inlet gas supply connection at the rear of the appliance. Install a fitting in the inlet pressure tapping suitable to connect to a manometer or magnahelic gauge. Range of scale should be 0 to 14 inch W.C. or greater to check inlet pressure
- Turn on gas supply at the field installed manual gas cock; turn on LP gas at tank if required.
- Turn the power switch to “ON” position.
- Adjust the thermostat set point to call for heat.
- Observe the gas supply pressure as the burner fires at 100% of rated input.
- Ensure inlet pressure is within specified range. Minimum and maximum gas supply pressures are specified in Gas Supply section of this manual.
- If gas pressure is out of range, contact the gas utility, gas supplier, qualified installer or service agency to determine necessary steps to provide proper gas pressure to the control.
- If gas supply pressure is within normal range, proceed to remove gas manometer and replace pressure tap fittings in the gas piping to the appliance.
- Turn on gas supply at the manual valve; turn on LP gas at tank if required.
- Turn the power switch to “ON” position.
- Adjust the thermostat temperature set point to the desired water temperature so the appliance will call for heat.
- Check appliance performance by cycling the system while you observe burner response. The burner should ignite promptly. Flame pattern should be stable, see “Maintenance-Normal Flame Pattern.” Turn system off and allow burner to cool, then cycle burner again to ensure proper ignition and flame characteristics.

#### IMPORTANT

Upon completion of any testing on the gas system, leak test all gas connections with a soap solution while the main burner is firing. Immediately repair any leak found in the gas train or related components. DO NOT operate an appliance with a leak in the gas train, valves or related gas piping.

### Regulated Gas Supply Pressures for DynaForce Boilers & Water Heaters

A stable gas supply pressure is important to avoid rough starts with machines like the DynaForce which use a 1 to 1 ratio control valve for internal gas pressure regulation.


Camus requires that the DynaForce models 2000 and above be supplied with no more than 1 PSI supply pressure. This means that lockup pressure must not exceed 1 PSI.

It is paramount that maximum lockup pressure be confirmed before any attempt is made to start up the appliance.

Operating the DynaForce at lockup pressures exceeding 1 PSI. is not recommended and could lead to delayed ignitions and damage to the appliance.

### 3.7 CHECKING DIFFERENTIAL AIR AND GAS PRESSURES (DR2000 – DR5000)

Figure 11: Checking Differential Air and Gas Pressures (DR2000 – DR5000)




- The 1 to 1 air/gas ratio control actuator has embossed markings identifying + air – air, + gas & - gas connections. Using a test hose assembly fitted with tees, connections can be made from the manometer to the appropriate ports on the actuator.
- Using tees connect a hose from the positive air and the negative air to each of the two sides of a manometer. This will allow the two pressure points to be measured while at the same time the actuator still receives the proper operating signal.
- If a second manometer is available it can be connected to the appropriate gas ports. Typically the gas signal will closely follow the air signal on all models. If the incoming gas pressure reduces significantly as the Variable Frequency Drive (VFD) accelerates to 60 Hz the gas signal may lag behind the air signal by up to 15%. This will occur once the actuator has driven downwards as far as it can go. The amount that the actuator has opened is registered by an indicator arm which is visible through the view window.
- As the appliance comes on and fires, record the maximum inches of water column which is achieved at 60 Hz on the VFD using start-up report form (93-0130). To adjust this differential pressure, use the adjusting screw on the air shutter to the fan. Readings are to correspond to the values in Table 8. In all cases the final adjustment is to be made using a combustion

analyzer. Depending on field conditions differential pressures will have to be adjusted accordingly. Typically with long lateral runs the differential signal as read will be reduced from the value shown in Table 9. The opposite will occur with tall stacks where drafts exceed negative 0.15"W.C.

- If the appliance will not light off and the blue 'main flame' light is coming on but not staying on then it will be necessary to adjust the low fire as explained in the detailed start-up procedure.

### 3.8 GAS TRAIN AND CONTROLS

Figure 12: Typical Gas Train




### 3.9 VENTING OF GAS VALVES AND PRESSURE SWITCHES

The optional gas pressure switches may be provided with threaded termination points to be vented to the atmosphere, outside the building. The gas pressure regulation function is provided by the ratio gas valve which does not require installation of a vent line. The optional gas pressure switches are installed in the upper chamber of the appliance. Threaded vent line connections from components requiring an external vent line are provided on the component. These vent line connection points may be accessed by removing the top of the appliance. Local codes may require the routing of these bleeds and vents to the atmosphere, outside the building. Proper routing of vent lines to the atmosphere from the factory supplied termination points is the responsibility of the installing contractor.

### 3.10 BURNER

Figure 13: Burner



This appliance uses a single cylindrical burner installed vertically into the cavity located in the center of the primary heat exchanger. There is a unique burner for each one of the sixteen models.

Burners may NOT be interchanged between different Btu/hr input models. The burner consists of a round mounting flange welded to a mixing tube. The top side of the mixing tube provides the transition which mounts the discharge from the combustion air fan into the burner. The bottom side of the mixing tube is attached to a stainless steel


perforated sleeve. This stainless steel sleeve is covered with a knitted alloy material that forms the burner port surface. The knitted burner port material is called metal fiber which is a unique alloy of iron, chrome, aluminum and several rare earth metals. This alloy is designed to operate stress free as a burner port surface. The burner port surface can sustain operation from a blue flame down to infrared conditions as the burner input varies. In order to maximize the operating life of the burner, the normal operating mode for the DynaForce is a blue flame. Infrared operation will occur only if air to gas adjustments is incorrect. If infrared operation is noted the cause must be corrected.

The burner mounting flange provides a flame view port and the mounting point for the hot surface igniter and the flame sensor. The hot surface igniter and flame sensor are removable from the burner mounting flange without removing the burner assembly from the heat exchanger. **Never use an open flame (match, lighter, etc.) to check gas connections.**

## PART 4 WATER CONNECTION

- Check all applicable local heating, plumbing and building safety codes before proceeding.
- If the appliance is installed above radiation level it must be provided with a low water cut-off device at the time of appliance installation (available from factory). Some local codes require the installation of a low water cut-off on all systems.
- A pressure relief valve is supplied with each DynaForce. The relief valve must be mounted in a vertical position and piped to the floor in a manner acceptable to the enforcing authority.
- Minimum operating system pressure should not drop below 30 PSIG. A minimum pressure relief valve setting of 30 PSIG is recommended.
- Be sure to provide unions and gate valves at inlet and outlet to the appliance so that it can be easily isolated for service. The provision of a flow setter valve at the appliance outlet will facilitate setting of the proper flow at the desired temperature rise at high fire. It is particularly important to confirm proper temperature rise for domestic hot water applications. Improper flows can lead to premature tube failure from erosion or scaling and will not be covered by warranty.
- This appliance is a low mass design which provides for instant heat transfer. Special attention to water flow rates will ensure that temperature rise is not excessive. See Table 9 (Page 19).
- To eliminate trapped air, install venting devices at high points in the system as well as in the piping on the suction of the pump and in the piping on the discharge of the appliance.
- Use suitable pipe hangers or floor stands to support the weight of all water and gas piping.
- Always pump toward the heat exchanger inlet. Never pump away from the exchanger since this will result in a low-pressure zone, which will allow localized boiling and result in heat exchanger damage.
- DynaForce must be installed so that the gas ignition system components are protected from water (dripping, spraying, rain, etc.) during appliance operation and service (circulator replacement, control replacement, etc.)

**Figure 14: Typical Space Heating System**



### 4.1 FREEZE PROTECTION

- Appliance installations are not recommended outdoors in areas where danger of freezing exists unless precautions are taken. Maintaining a mixture of 50% water and 50% propylene glycol is the preferred method of freeze protection in hydronic systems. This mixture will protect the appliance to approximately -35°F (-37°C). To maintain the same temperature rise across the appliance increase the GPM flow by 15% and the head loss by 20%.


The following example demonstrates the procedure to follow for calculating the revised head for the heat exchanger when using a water / glycol mixture.

- Given that Camus is showing a heat exchanger flow and head loss of 100 gpm @ 10 feet
- Increasing the flow by 15% now results in a head loss of 13 feet at 155 gpm (from B&G system syzer). At this increased flow Camus now recommends to increase the head loss by 20%.
- The requirement for the heat exchanger with water / glycol mixture will now be 115 gpm @ 15.6 feet. (ie.  $1.2 \times 13\text{ft.} = 15.6\text{ft.}$ )
- A similar procedure must be followed to calculate the additional head loss in pipe and fittings in order to arrive at the proper pump selection.
- For Outdoor installations a snow screen should be installed to prevent snow and ice accumulation on and around the appliance. Regular inspections should be made to ensure that air intake and vent are free of snow and ice. Always consider the use of a shelter such as a garden shed in lieu of direct exposure of the appliance to the elements. The additional protection afforded by the shelter will help to minimize nuisance problems with electrical connections and will allow easier servicing of the appliance under severe weather conditions.

### 4.2 WARNING REGARDING CHILLED WATER SYSTEMS

When an appliance is connected to an air conditioning system where the same water is used for heating and cooling, the chiller must be piped in parallel with the appliance. Appropriate flow control valves; manual or motorized must be provided to prevent the chilled water from entering the appliance.

**Figure 15: Chilled Water System**



### 4.3 INLET AND OUTLET CONNECTIONS

- All water connections meet American National Standard Pipe Threads (NPT).
- For ease of service, install unions on inlet and outlet of the appliance. The connection to the appliance marked "Inlet" on the header should be used for return from the system. The connection on the header marked "Outlet" is to be connected to the supply side of the system.

### 4.4 MINIMUM PIPE SIZE REQUIREMENTS

Minimum water pipe connections are as follow for DynaForce for single unit installations. The equivalent number of straight feet of pipe for each valve and fitting in the connecting piping must be considered to properly arrive at the total equivalent feet of straight pipe in the field installed piping to the appliance. See the piping requirements in Part 11 - Installation section of this manual. Consult factory if longer piping distances are required for a specific application.

### 4.5 PRIMARY HEAT EXCHANGER

This appliance uses stainless steel fin tubing to maximize the heat transfer process. The primary heat exchanger is comprised of vertical tubes welded directly into two circular stainless steel headers. This heat exchanger is design to withstand 160 PSIG working pressure. A series of "V" shaped baffles are installed between the individual tubes to control the movement of the flue products over the finned tubes to maximize efficiencies.

A factory recommended circulating pump ensures proper water flow during burner operation and creates enough water turbulence inside the stainless steel tubes and header that prevents the formation of sediments. Temperature rise and scale formation in the heat exchanger are controlled by the selection of a properly sized circulating pump.

The Camus designs are versatile and user friendly, they deliver optimal performance by taking full advantage of existing site conditions in order to maximize energy savings.

### 4.6 LOW WATER TEMPERATURE SYSTEMS

In applications where the heating system requires supply water temperatures below 110°F, connections may be made directly to the DynaForce. At incoming temperatures of 80°F or lower the DynaForce achieves maximum efficiency. Inlet temperatures must not drop below 40°F to prevent freezing.

### 4.7 INSTANTANEOUS WATER HEATER

An instantaneous water heater is designed to deliver hot water without the use of a storage tank. It is suitable for applications with variable load such as restaurants, condominiums, apartments and motels and typically used in conjunction with tempering valves to achieve temperature control. In some applications it may be appropriate to provide a flow through tank to act as a buffer. Consult factory for recommendations. (See Figure 10)

Figure 16: Typical Instantaneous Water Heating System




Table 7: Flow and Pressure Drop at a Given Temperature Rise (DR300-1000)

Model	10°F Rise		15°F Rise		20°F Rise*	
	US GPM	ΔP-Ft.	US GPM	ΔP-Ft.	US GPM	ΔP-Ft.
300	57.0	0.5	38.0	0.3	-	-
350	66.5	0.7	44.3	0.4	-	-
400	76.0	1.0	50.1	0.5	-	-
500	95.0	1.6	63.3	0.8	-	-
600	113.9	2.5	75.9	1.3	-	-
800	152.0	6.6	101.3	3.2	76.0	1.9
1000	189.8	11.4	126.5	5.4	95.0	3.2

\* Use for hydronic heating applications only

Table 8: Flow and Pressure Drop at a Given Temperature Rise (DR1200-5000)

Model	20°F Rise		25°F Rise		30°F Rise	
	US GPM	ΔP-Ft.	US GPM	ΔP-Ft.	US GPM	ΔP-Ft.
1200	113.8	10.0	91.0	6.6	75.8	4.7
1400	132.8	14.0	106.2	9.2	88.5	6.5
1600	151.8	14.1	121.4	9.3	101.2	6.5
1800	170.9	14.3	136.7	9.4	113.8	6.7
2000	189.8	20.8	151.8	13.6	126.4	9.7
2500	237.2	27.1	189.8	17.7	158.0	12.5
3000	284.6	27.3	227.7	17.8	189.6	12.7
3500	331.8	33.0	265.4	21.5	221.2	15.3
4000	379.5	36.9	303.6	24.0	253.0	17.1
4500	426.9	55.8	341.5	36.3	284.6	25.6
5000	474.0	60.0	379.2	39.0	316.0	27.5

Condensate from the DynaForce must be treated before being discharged to drain. pH level of the condensate is to be checked regularly and the neutralizing medium is to be replaced as required. A neutralizing cartridge is available from the factory. The DynaForce must be vented using only

special venting type AL29-4C stainless steel or equivalent, please follow instructions detailed below.

Only venting components listed by a nationally recognized testing agency or approved plastic vent may be used.

This appliance may be installed with conventional, sidewall or vertical venting. Conventional vented appliances operate with negative pressure in the vent pipe and may require a special vent adapter to increase the flue outlet diameter. Sidewall and vertically vented appliances operate with positive pressure in the vent pipe and may be directly connected to the flue outlet without the use of an increaser. Consult the vent pipe manufacturer's instructions for minimum clearances to combustible material for vent components. In the absence of instructions, the minimum clearance to combustible material is six inches.

Consult vent pipe manufacturer's instructions for proper method of sealing vent pipe sections and fittings. Do not use other sealants or adhesives except as expressly permitted by vent manufacturer's instructions.

Consult vent pipe manufacturer's instructions for vent system assembly. Follow vent pipe manufacturer's instructions if those instructions differ from this section.

#### **Conventional Venting**

Multiple appliances may be vented into a conventional chimney. The chimney must be lined with AL29-4C or equivalent and a barometric damper is to be provided as required for each appliance to control the draft.

A qualified professional using a proven vent-sizing program with input of accurate operating parameters must properly calculate sizing of the venting system. In applications where flue gas temperatures are lower than can support a Category II with conventional negative draft, it will be determined at the venting design stage that a positive pressure will be developed in the vent. It will then be necessary to either provide separate vents as for Category IV, to pressurize the boiler room, or to provide an extractor at the chimney outlet in order to maintain a negative draft in the chimney and allow common venting.

The chimney must be protected from down drafts, rain and debris by using a listed chimney cap. Approval of the installation will be at the discretion of authorities having jurisdiction.

#### **Sidewall Venting**

The maximum vent length is 100 equivalent feet. Vent pipe may be run through a vertical or horizontal chase provided that minimum clearances to combustible materials are maintained. The vent should terminate a minimum 12 inches above grade plus normally expected snow accumulation, or 7 feet above grade if located adjacent to public walkways. Do not install over public walkway where local experience indicates condensation or vapour from the boiler creates a nuisance or hazard. Minimum 3 feet above any forced air inlet located within 10 feet of vent termination. Minimum 4 feet below, 4 feet horizontally or above any door window or gravity air inlet. Minimum 4 feet horizontally from electric meters, gas meters, regulators and relief valves. Use appropriately designed thimbles when passing through combustible walls or roofs. Install fire stops where vent passes through floors, ceilings or framed walls. The fire stop must close the opening between the vent pipe and the structure. Locate vent terminal above combustion air intake terminal (if used) and no closer than

2 feet vertically or horizontally. Vertical venting requires flashing and a storm collar to prevent moisture from entering the structure. Vertical vent termination must be at least 2 feet plus the expected snow accumulation above the roof penetration height.

#### **4.10 WATER FLOW SWITCH (shipped loose)**


A water flow switch is shipped loose and is to be installed in the outlet piping on all heating boilers and hot water supply boilers. The flow switch is wired in series with the 24VAC safety control circuit. A diagnostic light will be indicated on the control display on a low flow condition.

#### **4.11 LOW WATER CUTOFF (If Equipped)**


If this boiler is installed above radiation level, a low water cut-off device must be installed at the time of boiler installation. Some local codes require the installation of a low water cut-off on all systems. Electronic low water cut-offs are available as a factory supplied option on all models. Low water cut-offs should be tested every six months. The normally open switch contact of the low water cutoff is to be wired in series with the flow switch. A diagnostic light will be indicated on the control display on a low flow condition.

**Caution:** remove jumper when connecting to 24 VAC circuit.

**Figure 17: Low Water Cut Off Electrical Connections (Watts)**



**Figure 18: Low Water Cut Off Electrical Connections (ITT)**



#### **4.12 RELIEF VALVE (shipped loose)**

This appliance is supplied with a relief valve sized in accordance with ASME Boiler and Pressure Vessel Code, Section IV ("Heating Boilers"). The relief valve is to be installed in the vertical position and mounted in the hot water outlet. No valve is to be placed between the relief valve, and the appliance. To prevent water damage, the discharge from the relief valve shall be piped to a suitable floor drain for disposal when relief occurs. No reducing couplings or other restrictions shall be installed in the discharge line. The discharge line shall allow complete drainage of the valve and line. Relief valves should be manually operated at least once a year.

**CAUTION**  
Avoid contact with hot discharge water

#### 4.14 CIRCULATING PUMP SELECTION

The appliance has a low mass stainless steel finned tube heat exchanger for fast response and high heat absorption. Selecting the proper pump will ensure that temperature rise does not exceed 35°F (19°C) and that heat exchanger tubes are not prematurely scaled or eroded.

##### 4.14.1 CIRCULATING PUMP OPERATION PRIMARY HEAT EXCHANGER

###### MOST IMPORTANT

This appliance is designed for continuous pump operation when the burner is firing. The circulating pump will run continuously when the power switch is in the "ON" position. As an optional feature a pump control system can be provided. The pump control option allows the appliance circulating pump to be cycled "ON" prior to the burner firing and cycled "OFF" some time after the set point is satisfied.

The operation of the circulating pump is controlled by the Honeywell SOLA temperature control. When the appliance is activated by a remote operating signal the pump will start and run for the operating cycle and for a post purge period based on temperature difference between inlet and outlet connections to the appliance.

To select the proper pump it is strongly recommended to consider the following:

- Need to know the required flow (GPM) and pressure drop for your appliance (see Table 9)
- Type of application, hydronic heating or Domestic Hot Water (DHW).
- For hydronic heating and DHW applications with normal water hardness choose a pump which will result in a temperature rise across the main heat exchanger of 20°F to 35 °F (17°C-19°C). If necessary use a flow setter valve to achieve the desired temperature rise.
- For DHW applications with other than normal water hardness choose a pump for the local water hardness conditions. When hardness levels exceed 17 grains per gallon consult factory for recommendations.

## PART 5 ELECTRICAL & CONTROLS

### **⚠ DANGER**

IT IS EXTREMELY IMPORTANT THAT THIS UNIT BE PROPERLY GROUNDED!

#### 5.1 ELECTRICAL CONNECTIONS

Table 9: Minimum Voltage Requirements

Model	Voltage Requirement	Maximum Over Current Protection	Full Load Amps
		[Amperes]	[Amperes]
300 - 2000	120VAC, 60Hz	12	7
2500 - 3000	120VAC, 60Hz	15	11
3500 - 4500	115/230VAC, 60Hz	24	14
5000	115/230VAC, 60Hz, 3 Phase	20	16

The combustion air fan motor operates on 230 VAC, 3 ph, 60 Hz on the DR1200 - 5000. This three phase voltage is generated by the variable frequency drive (VFD) and supplied directly to the fan motor. The appliance, when installed, must be electrically grounded in accordance with the requirements of the authority having jurisdiction or in the absence of such requirements, with the latest edition of the National Electrical Code ANSI/NFPA No. 70. When the unit is installed in Canada, it must conform to the Canadian Electrical Code, C22.1, Part 1 and/or local Electrical Codes.

- All wiring between the appliance and field installed devices shall be made with wire having minimum 220°F (105°C) rating.
- Line voltage wire exterior to the appliance must be enclosed in approved conduit or approved metal clad cable.
- The pump must run continuously when appliance is being fired.
- To avoid serious damage, DO NOT ENERGIZE the appliance until the system is full of water. Ensure that all air is removed from the pump housing and piping before beginning initial operation. Serious damage may result if the appliance is operated without proper flow.
- Provide the appliance with proper overload protection.



## 5.2 VARIABLE FREQUENCY DRIVE (DR1200 – 5000)

This appliance uses a Variable Frequency Drive (VFD) which provides power to the combustion fan. The fan motor operates on 230VAC 3 phase power. This three phase voltage is generated by the VFD and supplied directly to the fan motor. The VFD receives a modulating signal (4-20 mA or 2-10 VDC) from the local modulating control or a remote source based on water temperature to vary the frequency of the voltage supplied to the fan motor from 20 Hz up to 60 Hz. This varies the output of the combustion air fan from 20% up to 100% of capacity corresponding to the same variation in burner input. The VFD is driven towards 100% during the pre-purge portion of the start-up sequence. Once control self checks are completed, the VFD is provided with a signal to operate at soft start level for initial burner ignition. After main burner ignition is established, the modulating signal provided will use the VFD to vary the fan speed based VFD to vary the fan speed based on desired water temperature set point.

### CAUTION

The voltage output from the variable frequency drive to the combustion air fan is 230VAC, 3 Phase. **AVOID** contact with high voltage wiring

## 5.3 DIFFERENTIAL AIR PRESSURE SWITCH

A normally open differential air pressure switch is used to prove operation of the combustion air fan. The pressure switch sensing points are installed at the fan outlet as the air moves into the inlet of the burner. One point measures total pressure (+air) and is connected to a pitot tube facing the flow from the fan paddle wheel. The other point measures static pressure. Differential pressure at the switch will be affected by blockages at the fan inlet or at the flue discharge. A minimum differential pressure across the sensing points of the pressure switch proves operation of the combustion air fan. This is set in the factory and may be adjusted for field conditions. The diagnostics display will exhibit a Status of no Air Flow when the differential pressure switch detects a sustained low air condition. This condition could be caused by a number of factors including:

- Sensing line broken or loose fitting.
- Dirty filter or blocked vent.
- Steady high wind condition.
- Incorrectly set switch.

## 5.4 BLOCKED FLUE SWITCH

A normally closed block flue switch is used to shut down the appliance under the following conditions:

- 1) Air intake 50% blocked
- 2) Vent outlet 80% blocked

## 5.5 HIGH and LOW GAS PRESSURE SWITCHES (Optional)

High and low gas pressure switches are available as an option and are wired in series with the air flow switch. The high gas pressure switch is used to monitor the differential gas pressure between the outlet of the control valve and the fan inlet. If differential gas pressure exceeds the maximum setting of the pressure switch, the appliance will shut down and a low air condition will be indicated on the display panel. The low gas pressure switch is to monitor the minimum incoming gas supply pressure supplied to the gas train. If gas pressure falls below the minimum setting of the

pressure switch, the appliance will shut down and a low air condition will be displayed on the display panel.


## 5.6 HIGH LIMIT

A High Limit aqua-stat control is located at the back of the appliance and the control bulb is installed in a dry well in the heat exchanger header outlet. The setting of this control limits maximum discharge water temperature. A manual reset high limit will have a red reset button which must be pushed whenever water temperature has exceeded the set point of the manual reset limit. The temperature of the water in the heat exchanger must drop a minimum of 15°F (8.3°C) below the setting of the high limit control before the reset function can be activated. Whenever an appliance is supplied with both an auto reset and manual reset high limit always set the auto reset limit 10°F (5.5°C) below the manual reset limit. This will prevent nuisance tripping of the manual reset.

## 5.7 IGNITION CONTROL MODULE

DR300 –DR2000 utilize a direct spark ignition system. DR2500 – DR5000 utilize a standing pilot ignition method. The ignition control proves the presence of the proper ignition temperatures from the flame rod using a proof current (0.8µA DC), energizes the main gas valves, proves the presence of main burner flame, and provides for lockouts. The Alarm light will be lit on the ignition control module in the event of a fault.

Figure 19: Ignition Module



### 5.8.1 SERVICE PARTS

The DR300 –DR2000 utilizes a direct spark ignition system and the DR2500 – DR5000 uses a proven pilot ignition method. The electronic ignition module is not repairable. Any modification or repairs will invalidate the warranty and may create hazardous conditions that result in property damage, personal injury, fire, explosion and/or toxic gases. A faulty hot surface igniter or ignition module **MUST BE** replaced with a new factory approved unit only. A factory approved igniter, ignition control module and flame sensor for this specific unit is available from your local distributor. **DO NOT** use general purpose field replacement ignition modules, igniters or sensors. Each appliance has one ignition module, one hot surface igniter and one flame sensor.

## 5.7.2 IGNITION MODULE LOCKOUT FUNCTIONS

The ignition module may lockout in either a hard lockout condition requiring pushing of the reset button to recycle the control for a CSD1 requirement or a soft lockout condition which may be reset automatically once the error clears. A typical hard lockout fault can occur with single a trial for ignition CSD1 module. Pushing the reset button on the ignition control is the only way to reset an ignition module that is in a hard lockout condition. The reset button is located on the ignition module. Turning the main power "OFF" and then "ON" or cycling the thermostat will not reset a hard lockout condition. Wait five seconds after turning on the main power before pushing the reset button when the ignition module is in a hard lockout.

The ignition module will go into a soft lockout with the standard 5 seconds module after three sequential trials for ignition separated by 15 seconds between trials. A soft lockout condition will operate the combustion air fan for the post purge cycle (maximum 10 minutes) and then go into lockout and stay in this mode with the air flow light "OFF". The flame failure and all other lights up to the air flow light will remain "ON". If the control sensed fault is not corrected, the ignition module will continue in the soft lockout condition. A soft lockout condition may be reset by manually cycling the electronic thermostat or turning the main power switch "OFF" and then "ON" after the control sensed fault has been corrected.

## 5.8 DYNAFORCE CONTROLLER

This appliance uses a direct spark ignition control system. The operation of the DynaForce controller for the direct spark igniter proves the presence of main flame using a flame sensor proof current (0.8µA). A status point alarm of Flame Fail will be displayed on the main panel if the boiler fails to light after three (3) ignition attempts.

**Table 10: Connector Description**

Connector	Connector Description
J1	Flame Sensor, Ground Rod
J2	Fan Modulation
J3	Display
J4	24VAC Power
J5	Gas Valve, Safety Interlock String
J6	Safety Annunciation, Remote Operator
J8	24VAC Power, Outlet Sensor
J9	Inlet/DHW, Stack Sensor

### 5.8.1 Service Parts

The DynaForce controller is not repairable. Any modification or repairs will invalidate the warranty and may create hazardous conditions that result in property damage, personal injury, fire, explosion and/or toxic gases. A faulty direct spark igniter **MUST** be replaced with a new factory part. **DO NOT** use general purpose field replacement parts. Each appliance has one DynaForce Controller, one direct spark igniter and one flame sensor. A list of recommended spare parts is available.

## 5.8.2 Ignition Module Lockout Functions

The DynaForce controller may lockout in either a lockout condition requiring pushing the reset button to recycle the control for a CSD1 requirement or an alert condition. A typical lockout fault for the DynaForce controller occurs when the fan modulation signal is disconnected. Pushing the reset button on the control panel is the only way to reset the DynaForce Controller that is in a lockout condition. Turning the main power "OFF" and then "ON" or cycling the thermostat will not reset a lockout condition. Wait five seconds after turning on the main power before pushing the RESET button when the DynaForce Controller is in a lockout condition. Wait for the status LCD display to refresh indicating that the DynaForce Controller is ready before releasing the reset button.

The DynaForce Controller will go into an alert condition, for example, if the supply sensor is disconnected, flow switch, or air switch are not made. If the fault is not corrected, the boiler will stay in an alert condition. Once the fault is corrected, the boiler will automatically return to normal operating state

## 5.1 ERROR TABLE


The following tables provide a description of all the possible errors with the DynaForce appliance. Errors can be divided into two groups. Alert errors (will disappear when error is gone) and lockout errors (can only be reset by the RESET button).

When the control is in error the pump will be running. This is done to prevent the freezing of the central heating circuit when the boiler is in error during the winter period. For some non volatile lockouts the pump will not be running, see table below for more details.

**Table 11: Lockout codes**

#	Description
0	None
1-31	Internal hardware error
47	Flame rod to ground leakage
48	Static Flame
49	24VAC low/high
64	Fan speed not proved, ignition failure
67	Blocked flue condition
79	Heater Outlet high limit tripped
82	Stack limit
91	Inlet sensor fault
92	Outlet sensor fault
93	DHW sensor fault
95	Stack sensor fault
105	Flame detected out of sequence
106, 107, 108	Flame lost during run
132	Fan Speed Fault


Figure 20: Lockout Condition



To eliminate the lockout error,

- 1) Press the red bar, as circled above
- 2) Press the **[Lockouts]** button

Figure 21: Lockout History



- 3) Press **[Clear Lockout]**

Table 12: Alert Codes


#	Description
0	None
29	Burner Switch was turned OFF
30	Burner Switch was turned ON
61	Anti-short Cycle
62	Fan speed not proved
63	LCI off
64	Burner control firing rate < absolute min rate
66	Burner control rate (non-firing) was invalid, % vs. RPM
67, 68	Flow Switch, Blocked Flue Switch
75	Absolute max fan speed was out of range
76	Absolute min fan speed was out of range
79	Outlet high limit tripped
82	Stack limit tripped
91	Inlet sensor fault
92	Outlet sensor fault
93	DHW sensor fault
95	Stack sensor fault
109, 110	Ignition Failure Occured
291	Flame was not on at end of Ignition period
294	Abnormal Recycle
309	Not safe to start due to high limit
310	Flow Switch or Blocked Flue Switch tripped during Burn state
318	Stuck reset switch
361	Internal hardware error
-	
500	

# PART 6 CONTROL PANEL

## 6.1 APPLIANCE TEMPERATURE CONTROLLER

The appliance is provided with a control panel at the front. Operating controls are installed inside the control box and are accessible by undoing the thumb screw and swinging opening the door. The diagnostic information centre as well as the on/off switch, 24V fuse, and the appliance temperature controls reside on the control box door the ignition control module, VFD, transformer and relays are mounted on the internal panel.

Figure 22: Control Panel Front



The Boiler Temperature Controller for this appliance is the Honeywell SOLA R7910A control. It initiates the local call for heat and sets the target return (appliance inlet) water temperature. This controller offers a range of operation modes which provides set point as well as reset control. It provides the following:

- Readings of inlet and outlet water temperatures as well as  $\Delta T$  temperature rise.
- Operation as an auto reset limit.
- Operation as a control for inlet water temperature.
- $\Delta T$  heat exchanger protection algorithm
- Optional tank mounted sensor used in conjunction with inlet sensor.
- Adjustable; target temp, inter-stage differential, on delay between stages, minimum on time per stage, minimum off time per stage.
- Display of run hours for maintenance purposes. Counter wraps around at 10000 hours.
- Flame failure signal.
- Lumberg and Molex connectors for ease of service.
- Error message display in text
- Manual override of boiler input rate for combustion
- Pump exercising feature runs pump 10 seconds every three days of no pump operation.

### Levels of Access

Two access levels to simply the use of the boiler.

User – Access to general boiler and display settings and will allow adjustments to the central heating and domestic hot water setpoint.

Installer – Access to all user parameters and allows for changes to additional boiler parameters to allow for ease of startup and serviceability.

### Startup Display

Upon startup of the DynaForce the control panel displays the following.




Blue Icon	Appliance is operating normally
Red Icon	Appliance is in lockout condition

To move to the Homescreen simply touch the blue icon.

### NOTE

Due to the sensitivity of the touchscreen controller, using the backend of a pen/pencil is recommended for accuracy

Figure 23: Home Screen



## 6.2 OPERATION MENU

PARAMETER	DESCRIPTION
Demand	Central Heating (DRH)
	Domestic Hot Water (DRW)
Burner State	Current Status of DynaForce
Firing Rate	Target Fan Speed
Fan Speed	Actual Fan Speed
Inlet	Inlet Water Temperature [oF]
Outlet	Outlet Water Temperature [oF]
Stack	Stack Temperature [oF]
DHW	DHW Temperature [oF], if equipped
Header	Header Temperature [oF], if equipped
Outdoor	Outdoor Temperature [oF], if equipped

BUTTON	DESCRIPTION
Configure	Access DynaForce parameters (CH Parameters, DHW Parameters, Outdoor Reset, Pump Configuration)
Operation	Details of boiler operation (Setpoint, Firing Rate, Pump Status, Safety circuit)
Diagnostics	Manual firing rate, Analog/ Digital Status
Details	History, Trending, Pump Status, Outlet Temperature

Figure 24: Operation Menu





Figure 25: Annunciation Screen



Button	Menu Group Selection	Menu Group Selection	Parameter	Description
Operation		Burner switch	Burner Switch Button	Turns burner on/off without having to power down appliance
	Setpoint		Normal	Allows adjustment of Setpoint. The setpoint is controlled to the boiler inlet (Default 160°F)
			Time of Day	Setpoint with Night Setback feature
	Modulation		Demand	DHW, Central Heat, OFF
			Firing Rate	Actual fan speed (RPM)
			Outlet Sensor	Normal: SOLA has identified and is able to communicate with outlet sensor
				Open: outlet sensor is disconnected Shorted: outlet sensor is shorted
	Annunciation	LCI	LCI Load Control Input	ON, OFF
		ILK	ILK Interlock	ON, OFF
		PII	PII Interlock	Not used on the DynaForce
		Other	A1 Annunicator1	ON, OFF
			A2 Annunicator2	ON, OFF
			A3 Annunicator3	ON, OFF
			A4 Annunicator4	ON, OFF
			A5 Annunicator5	ON, OFF
A6 Annunicator6			ON, OFF	
A7 Annunicator7	ON, OFF			
A8 Annunicator8	ON, OFF			

### 6.3 DIAGNOSTICS MENU

Figure 26: Digital Diagnostics Menu











Figure 27: Analog Diagnostics Menu



Button	Menu Group Selection	Parameter	Description	
Diagnostics	Digital I/O	 122F	RED GREEN Digital I/O shows status of various components and safety's	
	Analog I/O	 58F Burner switch	Displays Various Parameters in the form of a bar graph - Outlet Temperature - Inlet Temperature - Firing Rate - Flame Signal - Fan RPM - Domestic Hot Water Temperature - Stack Temperature - 4-20mA Input Signal	
	Diagnostic Tests		Burner Switch Button	Turns burner on/off without having to power down appliance
		 1500 RPM	Fan Speed	Allows one to select the desired fan speed Min Speed: 2000 RPM Max Speed: Refer to DynaForce Test Sticker
			Start Test Button	After selecting desired fan speed, press Start Test button to operate at desired firing rate for 5 minutes
Burner Control		RED GREEN	Digital I/O shows status of various components and safety's	

## 6.4 DETAILS MENU

Figure 28: Details Menu



Button	Menu Group Selection	Parameter	Description
Details	Central Heat CH	CH Enable	Enabled: Call for heat is present
			Disabled: Call for heat is absent
		Status	Disabled (DRW Models)
			Enabled: (DRH Models)
		Demand Source	CH (DRH Models)
			DHW (DRW Models)
			Lead Lag (Cascade Models)
		Burner Demand	On: Burner is firing
			Off: Burner is not firing
		Heat Demand	Sensor only: Modulating to inlet sensor, constant temperature loop
			Remote STAT: 4-20mA or 0-10Vdc signal modulating to inlet sensor
			STAT Terminal: Remote operation through external remote operator (Default: STAT Terminal)
		Requested Rate:	Target Fan speed
		Setpoint Source:	Normal: Setpoint is stored into SOLA by user
			TOD: Operating to night setback temperature
			Outdoor Reset: Operating to outdoor reset temperature
			Remote Control: Operating through 4-20mA or 0-10Vdc signal
		OFF Setpoint	Burner shuts off when Inlet Temperature > CH Setpoint + Off Hysteresis
		Setpoint	Setpoint that SOLA is currently targeting to
		ON Setpoint	Burner turns on when Inlet Temperature < CH Setpoint - On Hysteresis
		CH Pump	On: Power is available to pump
			Off: Power is not available to pump
		Outlet Sensor State	Normal: SOLA has identified and is able to communicate with outlet sensor
			Open: outlet sensor is disconnected
			Shorted: outlet sensor is shorted
		Outlet temperature	Current outlet temperature (°F)
		Outlet high limit	Yes, high limit safety is enabled
		Outlet high limit setpoint	210°F
		4-20mA sensor state	Open: 4-20mA input is not detected
			Closed: 4-20mA input is detected

Button	Menu Group Selection	Parameter	Description
Details	Burner Control	Burner State	Displays current state of burner. Disabled, Locked out, Anti-short cycle, Standby, Normal, Preparing, Firing, Postpurge
		Firing rate control	Auto: Normal operation
			Manual: Manual firing rate is desired through Diagnostics Menu
		Firing rate	Actual fan speed (RPM)
		Flame Signal	20-22µA High Fire
			10-12µA Low Fire
		Sequence time	Running time for timed burner control operation (seconds)
		Delay time	Running timer for for appliance in delay state
		Lockout	Lockout code number
		Hold code	Hold code number
		Alarm reason	Text description of error
		Annunciator first out	First annunciator input related to lockout
		Annunciator hold	First annunciator input related to hold
		Pilot test hold	Off or Hold
		Remote STAT	Off
	Demand & Modulation	Demand source	CH (DRH Models)
			DHW (DRW Models)
			Lead Lag (Cascade Models)
		Firing rate	Actual fan speed (RPM)
		Demand rate	Target fan speed (RPM)
		Rate limiter	2000 RPM
		Limited rate	2000 RPM
	Rate Override	Disable	
	Override rate	0 RPM	
	Inlet	Inlet sensor state	Normal: SOLA has identified and is able to communicate with inlet sensor
			Open: inlet sensor is disconnected
			Shorted: inlet sensor is shorted
	Inlet temperature	Current outlet temperature (°F)	




Button	Menu Group Selection	Parameter	Description
Details	Fan	Fan speed	Current fan speed (RPM)
		Maximum fan speed	Varies with DR-Model
		Minimum fan speed	2000 RPM
	Flame detection	Flame detected	Yes or No
		Flame Signal	20-22µA High Fire
			10-12µA Low Fire
	Pilot test hold	On or off	
	Statistics	Burner cycles	Displays the number of cycles the burner has been activated
		Burner run time	Displays burner run time in hours
		Controller cycles	Number of cycles
		Controller run time	Duration of run time
	Stack limit	Stack limit enable	Enable single sensor non-safety
		Stack limit	Enabled
		Stack limit setpoint	Based upon vent material used. PVC: 149°F, CPVC: 194°F, Stainless Steel & AL29-4C: 300°F
		Stack sensor state	Normal: SOLA has identified and is able to communicate with outlet sensor
			Open: stack sensor is disconnected
			Shorted: stack sensor is shorted
	Stack temperature	Current stack temperature (°F)	
	Outdoor Reset	CH outdoor reset enable	Enabled or Disabled
		CH Setpoint source	Normal: Setpoint is stored into SOLA by user TOD: Operating to night setback temperature
			Outdoor Reset: Operating to outdoor reset temperature
			Remote Control: Operating through 4-20mA or 0-10Vdc signal
		Outdoor sensor state	Normal: SOLA has identified and is able to communicate with outlet sensor
			Open: outdoor sensor is disconnected
Shorted: outdoor sensor is shorted			
Outdoor temperature	Current outdoor temperature (°F)		

## 6.5 CONFIGURE MENU

The configure menu allows adjustment of setpoint temperatures for the user. On the installer level this allows

Figure 29: Configure Menu




### 6.5.1 System Identification & Access

Menu Group Selection	Parameter	Description
System Identification & Access	Product Type	Commercial Hydronic Boiler
	OS number	Part Number of SOLA Controller
	Software Version	Software version
	Date Code:	Release date of software
	Boiler Name	DynaForce Model Number
	Installation	Type of application

### 6.5.2 CH – Central Heat Configuration


Figure 30: Central Heat Configuration



Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description	
CH - Central Heat Configuration	Central Heat	CH enable	DRH - Enabled		
			DRW - Disabled		
		Demand Switch	Sensor only	Modulates to Inlet Sensor, Constant heat demand	
			Remote STAT	4-20mA or 0-10Vdc signal	
			STAT Terminal	Remote operation through external remote operator (Default: STAT Terminal)	
		Outdoor Reset	Enable	Outdoor Sensor must be connected to use this feature	
	Disable		(Default: Disable)		
	Setpoint	Setpoint Source	Local	Setpoint is defined by SOLA controller (Default: Local)	
			S2 (J8-6) 4-20mA	Setpoint is defined by external remote operator	
		Setpoint	45..210°F	Allows adjustment of Setpoint. The setpoint is controlled to the boiler inlet (Default 160°F)	
		Time of day Setpoint	45..210°F	Setpoint with Night Setback feature	
		Off hysteresis	5..30°F	Boiler Off = CH Setpoint + Off hysteresis (Default: 10°F)	
		On hysteresis	5..30°F	Boiler On = CH Setpoint - On hysteresis (Default: 10°F)	
		4mA water temperature	45..210°F	Corresponding setpoint for minimum signal. (Default: 45°F)	
		20mA water temperature	45..210°F	Corresponding setpoint for maximum signal. (Default: 160°F)	
		Modulation	Modulation Sensor	Outlet Sensor	
	Inlet Sensor				(Default)
	S5 (J8-11) sensor				Header Sensor
	Modulation Rate Source		Local		(Default)
		S2 (J8-6) 4-20mA		Must be selected with Remote STAT	

### 6.5.3 Outdoor Reset Configuration


Figure 31: Outdoor Reset Configuration



Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description
Outdoor Reset Configuration	Central Heat	Maximum outdoor temperature	-40..266°F	(Default: 266°F)
		Minimum outdoor temperature	-40..266°F	(Default: -40°F)
		Low water temperature	-40..266°F	???????????
		Minimum water temperature	-40..266°F	Minimum Setpoint Temperature (Default: 40°F)
		Maximum off point	-40..266°F	Maximum setpoint temperature (Default: 195°F)
		Maximum outdoor temperature	-40..266°F	(Default: 266°F)
	Lead Lag	Minimum outdoor temperature	-40..266°F	(Default: -40°F)
		Low water temperature	-40..266°F	???????????
		Minimum water temperature	-40..266°F	Minimum Setpoint Temperature (Default: 40°F)
		Maximum off point	-40..266°F	Maximum setpoint temperature (Default: 195°F)

### 6.5.4 DHW – Domestic Hot Water Configuration

Figure 32: Domestic Hot Water Configuration



Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description
DHW - Domestic Hot Water Configuration		DHW enable	Disabled	DRH - Disabled
			Enabled	DRW - Enabled
	Demand Switch	Sensor only	10kohm temperature sensor (Default)	
		DHW (S6) Switch	Aquastat	
	Modulation Sensor	DHW Sensor	10kohm temperature sensor	
		Outlet Sensor	10kohm temperature sensor	
		Inlet Sensor	10kohm temperature sensor (Default)	
	Setpoint	45..210°F	Allows adjustment of Setpoint. Controlled to the boiler inlet (Default 160°F)	
	Time of day Setpoint	45..210°F	Setpoint with Night Setback	
	Off hysteresis	5..30°F	Heater Off = DHW Setpoint + Off hysteresis (Default: 10°F)	
	On hysteresis	5..30°F	Heater On = DHW Setpoint - On hysteresis (Default: 10°F)	

### 6.5.5 DHW Storage Configuration

Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description
DHW Storage Configuration		DHW storage enable	Enabled	
			Disabled	
	Storage Time	5 min	0..60 min	
	Setpoint	45..210°F	Allows adjustment of Setpoint. The setpoint is controlled to the DHW sensor (Default 160°F)	
	Off hysteresis	5..30°F	Heater Off = DHW Setpoint + Off hysteresis (Default: 10°F)	
On hysteresis	5..30°F	Heater On = DHW Setpoint - On hysteresis (Default: 10°F)		

### 6.5.6 Warm Weather Shutdown Configuration

Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description
Warm Weather Shutdown Configuration		Enable	Disabled	<b>Enable/Disable warm weather shutdown algorithm</b>
			Shutdown after demand ends	
		Setpoint	60°F	When the outdoor temperature is below the preset Outdoor Setpoint a CH demand is created (Default: Disabled)

### 6.5.7 Pump Configuration

Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description
Pump Configuration	Central Heat Pump	Pump Control	Auto	Assigns the method for SOLA to control a Central Heating pump (Default: Auto, Pump is activated whenever a call for heat is present)
			ON	ON: Pump is constantly powered
		Pump Output	None	Assigns a central heat pump output terminal on the SOLA controller
			Pump A, B or C	
		Pump start delay	0 sec	Timer to delay pump start after call for heat is enabled
		Over run time	1..5 min	Post pump time (Default: 1 min)
		Boiler Pump	Pump Control	Auto
	ON			Refer to above
	Pump Output		None	Assigns the method for SOLA to control a Central Heating pump (Default: Auto, Pump is activated whenever a call for heat is present)
			Pump A, B or C	ON: Pump is constantly powered
	Pump start delay		0 sec	Timer to delay pump start after call for heat is enabled
	Over run time		1..5 min	Post pump time (Default: 1 min)
	Use for local (Stand-alone) demands		✓	
	Use for Lead Lag Master demands	✓		

Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description
Pump Configuration	DHW Pump	Pump Control	Auto	Refer to above
			ON	ON: Pump is constantly powered
		Pump Output	None	Assigns the method for SOLA to control a Central Heating pump (Default: Auto, Pump is activated whenever a call for heat is present)
			Pump A, B or C	ON: Pump is constantly powered
		Pump start delay	0 sec	Timer to delay pump start after call for heat is enabled
		Over run time	1..5 min	Post pump time (Default: 1 min)
	System Pump	Pump Control	Auto	Refer to above
			ON	ON: Pump is constantly powered
		Pump Output	None	Assigns the method for SOLA to control a Central Heating pump (Default: Auto, Pump is activated whenever a call for heat is present)
			Pump A, B or C	ON: Pump is constantly powered
		Pump start delay	0 sec	Timer to delay pump start after call for heat is enabled
		Over run time	1..5 min	Post pump time (Default: 1 min)


Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description	
	Auxiliary 1 Pump	Pump Control	Auto	Refer to above	
			ON	Refer to above	
		Pump Output	None	Assigns the method for SOLA to control a Central Heating pump (Default: Auto, Pump is activated whenever a call for heat is present)	
				Pump A, B or C	ON: Pump is constantly powered
			Pump start delay	0 sec	Timer to delay pump start after call for heat is enabled
		Over run time	1.5 min	Post pump time (Default: 1 min)	
		Use for local (Stand-alone) demands	✓		
		Use for Lead Lag Master demands	✓		
	Auxiliary 2 Pump	Pump Control	Auto	Refer to above	
			ON	Refer to above	
		Pump Output	None	Assigns the method for SOLA to control a Central Heating pump (Default: Auto, Pump is activated whenever a call for heat is present)	
				Pump A, B or C	ON: Pump is constantly powered
			Pump start delay	0 sec	Timer to delay pump start after call for heat is enabled
		Over run time	1.5 min	Post pump time (Default: 1 min)	
		Use for local (Stand-alone) demands	✓		
		Use for Lead Lag Master demands	✓		

### 6.5.8 Statistics Configuration

Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description
Statistics Configuration		Auxiliary pump cycles		Displays the number of cycles the auxiliary pump has been activated
		Boiler pump cycles		Displays the number of cycles the boiler pump has been activated
		Burner cycles		Displays the number of cycles the burner has been activated
		Burner run time		Displays burner run time in hours
		CH pump cycles		Displays the number of cycles the CH pump has been activated
		DHW pump cycles		Displays the number of cycles the DHW pump has been activated
		System pump cycles		Displays the number of cycles the system pump has been activated
		Auxiliary 2 pump cycles		Displays the number of cycles the auxiliary 2 pump has been activated

### 6.5.9 Stack Limit


Figure 33: Stack Limit Configuration



Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description
Stack Limit		Stack limit setpoint	149°F	Based upon vent material used. PVC: 149°F, CPVC: 194°F, Stainless Steel & AL29-4C: 300°F

### 6.5.10 Burner Control Timing and Rates

Figure 34: Burner Control Timing and Rates



Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description
Burner Control Timing and Rates		Prepurge rate	3000 RPM	Prepurge fan speed (Default: 3000 RPM)
		Prepurge time	30 sec.. 5 mins	Prepurge time (Default: 30 sec)
		Postpurge rate	3000 RPM	Postpurge fan speed (Default: 3000 RPM)
		Postpurge time	30 sec.. 5 mins	Postpurge time (Default 1 min)

### 6.5.11 Burner Control Ignition

Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description
Burner Control Ignition		Lightoff rate	2000..3000 RPM	Ignition Fan speed (Default: 2500 RPM)

### 6.5.12 Sensor Configuration

Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description
Sensor Configuration		S2 (J8-6) sensor	4-20mA	4-20mA Input Signal
		S5 (J8-11) sensor	10K NTC single non-safety	Outdoor Sensor: Standalone boiler or Slave boiler, Header sensor: Master boiler
		S6S7 (J9-1,3) sensor	10K NTC single non-safety	DHW Sensor (DRW Only)

### 6.5.13 Lead Lag Slave Configuration

Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description
Lead Lag Slave Configuration		Slave enable	Disabled	Determines if a slave boiler is available (Default: Disabled)
		Base load rate	3000 RPM	??? How does this work?
		Demand to firing delay	2 min	Time delay between boiler startup (Default: 2 min)
		Modbus address	Varies with DynaForce designation	Boiler address for each boiler, must be in sequential order

### 6.5.14 Lead Lag Master Configuration

Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description		
Lead Lag Master Configuration		Master enable	Disabled	Determines if a master boiler is available (Default: Disabled)		
		CH Setpoint	160°F	Setpoint desired here needs to match Setpoint in "CH - Central Heat Configuration"		
		CH time of day setpoint	130°F	Setpoint with Night Setback feature		
		Modbus address	MB1.. MB8	Varies with DynaForce designation		
	[Advanced Settings]					
	Modulation	Modulation backup sensor	Lead outlet sensor		Backup sensor is used, if primary sensor has failed	
		Off hysteresis	10°F		Heater Off = CH Setpoint + Off hysteresis (Default: 10oF)	
		On hysteresis	10°F		Heater On = CH Setpoint + On hysteresis (Default: 10oF)	
	Central Heat	Demand Switch	STAT		Remote operation through external remote operator (Default: STAT Terminal)	
			Remote STAT		4-20mA	
		Setpoint source	Local		Fixed setpoint (Default: Local)	
				4-20mA	Varying setpoint through 4-20mA signal	
		Setpoint	45..210°F		Allows adjustment of Setpoint. The setpoint is controlled to the header sensor (Default 160oF)	
		Time of day Setpoint	45..210°F		Setpoint with Night Setback feature	
		4mA water temperature	45..210°F		Corresponding setpoint for minimum signal. (Default: 45oF)	
		20mA water temperature	45..210°F		Corresponding setpoint for maximum signal. (Default: 160oF)	
		Outdoor reset	Enable			Outdoor Sensor must be connected to use this feature
			Disabled			(Default: Disable)

Menu Group Selection	Sub-Menu Group Selection	Parameter	Selection	Description	
Lead Lag Master Configuration	Warm Weather Shutdown	Enable	Disabled	Boiler stays in Standby when outdoor temperature exceeds set temperature (Default: 60°F)	
		Setpoint	60°F		
	Algorithms	Lead selection method	Sequence Order		Lead boiler firing can be based on 2 methods. (Default: Measured Run Time)
			Measured Run Time		
		Lag selection method	Sequence Order		Slave boiler firing can be based on 2 methods. (Default: Measured Run Time)
			Measured Run Time		
		Lead rotation time	24 hours		Number of hours a boiler remains leader determined automatically by SOLA (Default: 24 hrs)
		Force lead rotation time	24 hours		Number of hours a boiler remains leader determined manually (Default: 24 hrs)
	Rate Allocation	Base load common	40%	Minimum rate shared across all boilers	
	Add Stage	Error threshold	5°F	Temperature below setpoint to turn on boiler	
		Interstage delay	30 secs	??? How does this work?	
	Drop Stage	Error threshold	5°F	Temperature below setpoint to turn on boiler	
		Interstage delay	30 secs	??? How does this work?	

## 6.2 VARIABLE FREQUENCY DRIVE (DR1200 - 5000)

The variable frequency drive (VFD) has a factory set security code which has to be entered before any adjustments can be made. The VFD has 50 parameters, which can be adjusted. At present only the following are pertinent:

**Table 13: Variable Frequency Drive Parameters**

Parameter #	Function	Settings
1	High/Low Voltage Input Voltage 120, 220-240, 460-480	01 02
2	Carrier Frequency	03
4	Stop Method	03
5	Standard Speed Source	04 (03 for 2- 10 VDC)
19	Acceleration Time	120 sec
20	Deceleration Time	60 sec
28	Fixed Boost	1.0
36	Preset Speed	29
38	Skip Bandwidth	3.0
45	Speed at Minimum Signal	<ul style="list-style-type: none"> <li>• 2500 – 3000: 25</li> <li>• 3500 – 5000: 14-18</li> </ul>
46	Speed at Maximum Signal	<ul style="list-style-type: none"> <li>• All Models: 60</li> </ul>
50	Fault History	View Only
51 thru 58	Miscellaneous	View Only




## PART 7 COMPONENTS

### 7.1 HOT SURFACE IGNITER (GLOW BAR)

The silicon carbide igniter is inserted directly through the fan flange and held in place by two screws. A hold down bracket as well as sealing gasket above and below the igniter assures a good seal. Care must be taken when removing and/or installing the igniter since the silicon carbide element is brittle. Always remove the igniter prior to removing the fan assembly for inspection of the burner and heat exchanger. Properly prepared igniter will have a bead of silicone sealing the end mounting bracket to the ceramic shaft.

Figure 34: Hot Surface Igniter




During trial for ignition a properly operating igniter will generate 3.2+/-0.2A which is the proof current required by the ignition module for reliable and consistent operation. It is recommended that the hot surface igniter be replaced every 4,000 hours of appliance operation to maintain peak ignition efficiency.

### 7.2 FLAME SENSOR

The flame sensor is inserted directly through the fan flange and is screwed into the fan flange. Care must be taken, when installing the flame sensor, to align it perpendicular to the fan flange and parallel to the burner tube and not to over tighten. Always remove the flame sensor prior to removing the fan assembly for inspection of the burner and heat exchanger.


Figure 35: Flame Sensor



The ignition module relies on the flame sensor to provide a flame rectification signal. Oxide deposits, improper placement or damaged ceramic insulator will result in insufficient signal leading to ignition module lock out. For proper operation minimum 0.8  $\mu$ A DC must be fed back to the module. Oxide deposit on the sensor rod must be removed with steel-wool. Do not use sand-paper since this will contaminate the surface.

### 7.3 COMBUSTION AIR FAN

Figure 36: Fan, Burner, Hot Surface Igniter and Flame Sensor Arrangement



DynaForce uses a sealed air fan to provide combustible air/gas mix to the burner and push the products of combustion through the heat exchanger and venting system. The fan assembly consists of a sealed housing and fan wheel constructed from spark resistant cast aluminum. The fan is operated by a fully enclosed 230 VAC, 3 Phase electric motor. The fan housing and motor assembly is fully sealed and SHOULD NOT be field serviced. The power draw of the motor is proportional to the modulated gas input rate of the appliance.

### 7.4 INNER JACKET

The inner jacket assembly is constructed from a special corrosion resistant stainless steel. This includes both the primary heat exchanger chamber and the secondary heat exchanger chamber. All screws and fasteners used for assembly of the inner jacket and secondary heat exchanger chamber are also stainless steel.

**DO NOT mix stainless steel and standard plated fasteners when disassembling and reassembling the inner jacket sheet metal components. Standard plated fasteners will be damaged by the flue product condensate when used on the inner jacket assemblies.**

### 7.5 OUTER JACKET

The outer jacket assembly is constructed from mirror finish stainless Steel. This ensures a long life for the jacket assembly, with full integrity

### 7.6 VENTING TRANSITION

All appliances are shipped with a rectangular to round stainless steel adapter. Depending on the appliance category an increaser will be required for the proper vent configuration. Please refer to Table 4 dimensions and specifications.

When installing Category II or IV appliances care must be taken to properly seal all joints and provide slope for drainage of condensate.

## PART 8 FIELD STARTUP PROCEDURE

### 8.1 CHECKING THE INSTALLATION

- Inspect the connections for water, gas and electricity.
- Confirm that water is being pumped toward the heat exchanger inlet. Never pump away from the exchanger since this will result in a low-pressure zone, which will allow localized boiling and result in heat exchanger damage.
- Power to the boiler and pump must be from the same circuit to prevent the boiler firing in case the pump is inadvertently shut off.
- Inlet gas pressure must be a minimum of 4" W.C. for natural gas and 11" W.C. for propane.
- With the boiler off, open the main gas supply valve and vent the trapped air from the piping leading to the boiler. Confirm that all gas connections to the heater are tight and that there are no missing test plugs.
- Connect a manometer to obtain the differential air pressure between negative and positive ports. See Figure 7.
- The air/gas ratio controller automatically adjusts to match the air signal on the gas side. In this way true mass flow control of air/gas mix is achieved. Typical differential air settings are listed in Table 8. All boilers are test fired and factory set. A test sticker with actual reading is affixed to the unit.

Refer to Part 3 of the manual for recommendations on setting combustion characteristics.

### 8.2 CHECKING THE CONSTRUCTION

- Check the boiler wiring to see that it agrees with the wiring diagram supplied.
- Confirm that all terminal strips and field connections are identified.
- Confirm that the SmartFlame control is set in the proper mode. In remote mode an external controller determines the set point and the stage contacts on the SmartFlame are always closed. Auto reset limits are fixed in all Modes.
- With the firing valve in the off position, switch on power to the boiler. The fan motor will accelerate until the airflow light deenergizes. If a light remains on past the operator light, the ignition sequence will not proceed. During trial for ignition the red flame failure light may light up momentary.
- Once all lights past the operator are deenergized the ignition module will try for ignition. When the igniter is hot enough, the ratio gas valve actuator is energized and if ignition is accomplished the blue main burner light will come on and remain lit. If ignition is not accomplished, the red flame failure light will energize and two more ignition trials will be made 15 seconds apart. The control will then proceed to lockout and must be reset by momentarily interrupting power. It is normal during initial start up, when air is being purged from the piping, to require two to three tries before successful ignition.
- With the boiler running, check for flue gas leaks along the inner cabinet joints and around the flue outlet. Some minor leakage is acceptable.
- Repair any major leaks prior to the next step.

- At the factory adjustments were made to achieve proper input and acceptable burner performance at full input and at minimum input.
- Depending on field conditions, the CO<sub>2</sub> trim valve may require some minor adjustment at full input. Refer to Figure 8. CO<sub>2</sub> may be set in the range of 8.5% to 9.0% at full fire and 7.5% to 8.0% at low fire. For propane, reading will be approximately 1.5% higher. Adjustment at minimum input can be done at the low fire adjustment screw by first removing the brass cap. Turning adjustment screw clockwise will increase CO<sub>2</sub>.

### 8.3 GAS VALVE ADJUSTMENT PROCEDURE

If adjustment of the gas valve is required use the following procedure.

In order to perform adjustments to the gas valve the DynaForce must be firing before proceeding.

Figure 35: DR 300 – 400 Gas Valve





Figure 36: DM 500 - 1800 Gas Valve



To adjust the high-fire setting (DR 300 – 1800)

Use the DynaForce Control Panel:

- 1) Press **[DIAGNOSTICS]** button
- 2) Press **[Diagnostic Tests]** button
- 3) Move the firing rate slider to maximum RPM as indicated by the test sticker
- 4) Press **[Start Test]** to operate the boiler at max fire for 5 minutes.

Locate the input adjustment screw on the top side of the gas valve.

	Increase CO2	Decrease CO2
<b>High Fire Adjustment</b>	Counter-Clock Wise	Clockwise

After adjusting the screw wait a moment for the combustion levels to stabilize before attempting to make any further adjustments. Continue this procedure until combustion levels are satisfied.

To adjust the low fire setting (DR 300 – 1800)

Use the DynaForce Control Panel:

- 1) Press **[DIAGNOSTICS]** button
- 2) Press **[Diagnostic Tests]** button
- 3) Move the firing rate slider to 2000 RPM
- 4) Press **[Start Test]** to operate the boiler at max fire for 5 minutes.

The DynaForce should respond immediately and fire at 2000 RPM. When this is achieved locate the low fire adjustment screw as illustrated in Figure 36 and 37.

	Increase CO2	Decrease CO2
<b>Low Fire Adjustment</b>	Clockwise	Counter-Clock Wise

When the correct combustion values are achieved replace the screw cap back on to the gas valve.


- This boiler is designed for low fire soft start. At the start of trial for ignition the fan will decelerate to minimum fire and will light off at low fire before ramping up towards full input depending on the 4 – 20 mA signal from the controller.
- Shut power off to the heater and open the firing valve. Switch power back on and allow the burner to fire. Ignition should be smooth. Normally the differential gas pressure will be identical to the differential air pressure. Actual differential pressure may vary from the numbers on the test label due to the field conditions and sample variations. Always make adjustments to meet the recommended CO<sub>2</sub> levels. Adjust high fire first followed by low fire adjustment.

To adjust the high-fire setting (DR 1800 – 5000)

One or more manometers should be connected to the DynaFlame before proceeding to the next step to monitor the air and gas signal. Refer to Section 3.7 of this manual for details on connecting monitors.

Use the DynaForce Control Panel:

- 1) Press **[DIAGNOSTICS]** button
- 2) Press **[Diagnostic Tests]** button
- 3) Move the firing rate slider to 100.0%
- 4) Press **[Start Test]** to operate the boiler at max fire for 5 minutes.




Locate the metering valve on the gas train.

	Increase CO2	Decrease CO2
<b>High Fire Adjustment</b>	Counter-Clock Wise	Clockwise

Turn the screw 1/8 turn in either way for each adjustment to keep track of the adjustments. After adjusting the screw wait a moment for the combustion levels to stabilize before attempting to make any further adjustments. Continue this procedure until combustion levels are satisfied.

To adjust the low-fire setting (DR 2000 – 5000)

**Figure 37: SKP 55 Gas Valve**



- 1 Adjustment of low fire bias
- 2 Connection for air pressure (+) sensing line
- 3 Connection for the air pressure (-) sensing line
- 4 Connection for the gas pressure (-) sensing line
- 5 Connection for the gas pressure (+) sensing line
- 6 Position indicator

Use the DynaForce Control Panel

- 1) Press **[DIAGNOSTICS]** button
- 2) Press **[Diagnostic Tests]** button
- 3) Move the firing rate slider to 20.0%
- 4) Press **[Start Test]** to operate the boiler at max fire for 5 minutes.

	Increase CO2	Decrease CO2
<b>Low Fire Adjustment</b>	Clockwise	Counter-Clock Wise

**Table 13: Combustion Values**

DynaForce Combustion Values				
	Natural Gas		Propane	
	CO <sub>2</sub>	CO	CO <sub>2</sub>	CO
<b>Max. Fire</b>	8.5% - 9.0%	<100 PPM	9.5% - 10.0%	<100 PPM
<b>Min. Fire</b>	8.0% - 8.5%	<100 PPM	9.0% - 9.5%	<100 PPM

- Allow the water temperature to rise so that the heater cycles on the operator.
- Check the temperature rise across the heat exchanger. This will be item ΔT on the SmartFlame control. For hydronic applications and for domestic hot water, a rise exceeding 30°F is not normally recommended.

- Allow the unit to cycle on the limit. This can be done by gradually restricting outlet water flow. The auto reset limits are set at 200°F for domestic hot water and hydronic heating.

- Remove fan inlet filter. During trial for ignition, block 50% of the fan inlet opening. The display should show 'ILK not closed'. If it does not, slowly turn the adjustment on the normally closed blocked flue switch counter-clockwise until the air flow light energizes.
- Check the air proving switch. Remove the restriction from the fan inlet and reset the power on the control panel. A properly set air switch will cause the air flow light to deenergize at a fan speed between 15Hz and 20Hz on the VDF.
- Check the ignition retries circuit.
- Shut the main gas off to the unit and allow it to try for ignition. Trial for ignition should commence within 30 seconds.

### 8.4 COMMISSIONING APPLIANCE

- Remove manometers and replace inlet gas pressure test plug.
- Fill out start up report for each heater. Be sure to record all settings and readings. Retain a copy of report for future reference.
- Start up is now complete and heater may be placed into service.

### 8.5 CASCADE SETUP

All SOLA controllers are programmed with a default address of 1. The address of the slave controller in the system must have a unique address (1..8).

#### Rotation

Rotation time is configurable and is in sequential order according to address (1-2-3-4; 2-3-4-1)

#### Demand to Firing Delay

The length of time to wait between requesting a slave SOLA to fire and detecting that it has failed to start.

#### Base Load Rate

This algorithm is implemented where a heat demand is to be evenly distributed across all boilers to optimize burner on time.

#### Slave State


Slave Status Manager	
Unknown	Table entry is unused or empty
Available	Slave is operational and ready to use
Add Stage	Stage is getting ready to fire
Suspend Stage	Stage was getting ready but is not needed
Disabled	Slave is locked out or disabled
Recovering	Slave is in time delay to verify that it is operational before considered to be available

#### Wiring the Cascade Setup

Use MB2 Terminals to wire Cascade appliances

	Master	Slave 2	..	Slave 7
<b>J3, MB2</b>	A	A	..	A
	B	B	..	B
	C	C	..	C

**Figure 38: Cascade Wiring Setup (Left: Master, Right: Slave)**



#### Programming the Cascade Setup

##### Master Appliance

Turn on the Master appliance and wait until the blue icon appears.

- 1) Press the blue icon
- 2) Press the **[Configure]** button
- 3) Press **[Login]**
- 4) Enter the Installer password and press **[OK]**
- 5) Scroll down and click on Lead Lag Master Configuration
- 6) Press Master enable and select 'Enabled' and press **[OK]**

- 7) Confirm Modbus address = 1
- 8) Adjust additional Cascade parameters, if necessary. Refer to 6.5.14 for parameter list
- 9) The Master appliance is now setup. **DO NOT** turn off the Master appliance.

#### Slave Appliance

Turn on the Slave appliance and wait until the blue icon appears.

- 1) Press the blue icon
- 2) Press the **[Configure]** button
- 3) Press **[Login]**
- 4) Enter the Installer password and press **[OK]**
- 5) Scroll down and click on Lead Lag Slave Configuration
- 6) Press Slave enable and select 'Enabled' and press **[OK]**
- 7) Modbus address is to be sequential for each additional appliance.
- 8) Adjust additional Cascade parameters, if necessary. Refer to 6.5.13 for parameter list
- 9) The Slave appliance is now setup. **DO NOT** turn off the Slave appliance

## PART 9 TROUBLE SHOOTING

COMPONENT	FAILURE MODE	ANALYSIS
Incoming Power	<ul style="list-style-type: none"> <li>Two wires interchanged</li> </ul>	<ul style="list-style-type: none"> <li>No effect on safety</li> <li>Live and Neutral wires are interchanged.</li> </ul>
Transformer Tripped	<ul style="list-style-type: none"> <li>The 24Volts and 120 Volts wired are interchanged</li> </ul>	<ul style="list-style-type: none"> <li>Transformer immediately burns out, replace transformer</li> </ul>
Relief Valve	<ul style="list-style-type: none"> <li>System pressure exceeds relief valve setting</li> </ul>	<ul style="list-style-type: none"> <li>Replace the standard relief valve with a higher rated valve up to the maximum pressure of the heat exchanger.</li> <li>Improperly sized expansion tank.</li> </ul>
Flow Switch	<ul style="list-style-type: none"> <li>Flow Switch contacts are open</li> </ul>	<ul style="list-style-type: none"> <li>Verify for closed valves or obstructions in boiler piping</li> <li>Verify that all air has been purged from the system</li> <li>Verify that wiring is correct</li> </ul>
Flame Failure	<ul style="list-style-type: none"> <li>The boiler has failed to ignite the burner</li> </ul>	<ul style="list-style-type: none"> <li>To reset the module refer to section 5.8.2</li> <li>Verify that all air has been purged from gas line</li> <li>Inspect spark electrode and related wiring for damage and connection errors</li> <li>Inspect hot surface igniter and related wiring for damage and connection errors</li> <li>DR300 – 1000: ??????????</li> <li>DR 1200 – 2500: Verify igniter is glowing</li> <li>DR 3000 – 5000: Verify pilot is lit</li> <li>Inspect flame sensor and associated wiring. Replace if necessary</li> <li>Verify that boiler is properly grounded</li> <li>Verify incoming gas supply pressure and that it coincides with Table 6.</li> <li>Verify that the vent/ air inlet piping (if equipped) are correctly installed and obstructions are not present.</li> <li>Verify 24 VAC (DR 300 – 1800) and 115VAC (DR 2000 – 5000) is being supplied to the gas valve transformer from the DynaForce Controller during ignition. Check wiring from DynaForce Controller and Gas Valve Relay. If a signal cannot be detected, the DynaForce Controller needs to be replaced</li> <li>If 24 VAC is present, check the outlet of the valve to ensure that gas is flowing. When the valve is energized a change in pressure should occur, if no change is detected the gas valve has failed to open or it is passing insufficient amount of gas. If this is an initial startup increase the low fire gas setting by ¼ turn clockwise.</li> <li>Inspect the burner. Refer to Burner Maintenance in section 10.5</li> <li>Replace the DynaForce Controller</li> </ul>
Flame Disappears During a Run Cycle	<ul style="list-style-type: none"> <li>The DynaForce boiler was running and flame signal suddenly disappeared.</li> <li>Lockout: 47</li> <li>Alert: 291, 292, 293, 294</li> </ul>	<ul style="list-style-type: none"> <li>Verify that all air has been purged from gas line</li> <li>Verify that boiler is properly grounded</li> <li>Inspect flame sensor and associated wiring. Replace if necessary</li> <li>Check for flame sensor cracks in the insulator or continuity to ground</li> <li>Adjust the air proving switch. Turn counter-clockwise to reduce sensitivity</li> <li>Verify incoming gas supply pressure and that it coincides with Table 6.</li> <li>Verify that the gas line connections to the boiler are adequate. Refer to Table 5.</li> <li>Verify that the vent/ air inlet piping (if equipped) are correctly installed and obstructions are not present</li> <li>Verify that 24 VAC is being supplied to the gas valve during operation. If a signal cannot be detected, the transformer needs to be replaced</li> <li>Inspect the burner. Refer to Burner Maintenance in section 10.5</li> <li>Replace the DynaForce Controller if necessary</li> </ul>

SYMPTOM	FAILURE MODE	ANALYSIS
<b>Noisy Operation</b>	<ul style="list-style-type: none"> <li>Supply Gas Issue</li> </ul>	<ul style="list-style-type: none"> <li>Refer to Part 3 Gas Connection in this manual.</li> <li>Natural Gas Pressure reads between 3" w.c. and 14" w.c.</li> <li>L.P. Gas Pressure should be at 11" w.c.</li> </ul>
	<ul style="list-style-type: none"> <li>Air/Gas Mixture Issue</li> </ul>	<ul style="list-style-type: none"> <li>Refer to Section 8.3 Gas Valve Adjustment Procedure for proper combustion setting.</li> </ul>
	<ul style="list-style-type: none"> <li>Air Inlet and/or Vent configuration</li> </ul>	<ul style="list-style-type: none"> <li>Refer to Part 2 Air Inlet and Venting</li> </ul>
	<ul style="list-style-type: none"> <li>Dirty/ Damaged Burner</li> </ul>	<ul style="list-style-type: none"> <li>Refer to Burner Maintenance in section 10.5 of this manual for the burner removal and inspection procedure. Clean or replace the burner, if required.</li> </ul>
	<ul style="list-style-type: none"> <li>Air in the piping system</li> </ul>	<ul style="list-style-type: none"> <li>Purge all air from the piping system</li> </ul>
	<ul style="list-style-type: none"> <li>Incorrect Igniter Gap (DR300 – 1000)</li> </ul>	<ul style="list-style-type: none"> <li>Check that spark gap is 9/64"</li> </ul>
<b>Auto Reset High Limit Trips</b>	<ul style="list-style-type: none"> <li>The outlet temperature has exceeded the setpoint temperature specified.</li> </ul>	<ul style="list-style-type: none"> <li>Verify that the system is full of water and that all air has been properly purged from the system.</li> <li>Verify that the boiler is piped properly. Refer to Piping Diagrams in Section 12 of this manual.</li> <li>Verify that 120VAC is being supplied to the boiler pump on a call for heat. If voltage cannot be detected check wiring.</li> <li>Verify that the pump is circulating when 120VAC is detected. If not, pump impeller may be stuck. Use a flat head screwdriver on face of pump to turn impeller manually</li> <li>If 120VAC is present during a call for heat, but the pump still does not circulate, replace the pump.</li> <li>Replace the main DynaForce Controller if necessary</li> </ul>
<b>Manual Reset High Limit Trips</b>	<ul style="list-style-type: none"> <li>Manual Reset Safety High Limit tripped, outlet temperature in excess of 210°F</li> <li>Alert: 309, 310, 311, 312, 313, 314, 315</li> </ul>	<ul style="list-style-type: none"> <li>Verify that the capillary tube is broken. If this is the case, replace Manual Reset High Limit</li> <li>Verify that the system is full of water and that all air has been properly purged from the system.</li> <li>Verify that the boiler is piped properly. Refer to Piping Diagrams in Section 12 of this manual.</li> <li>Verify that 120 VAC is being supplied to the boiler pump on a call for heat. If voltage cannot be detected check wiring.</li> <li>Verify that the pump is circulating when 120 VAC is supplied. If so, pump impeller may be stuck. Use a flat head screwdriver on face of pump to turn impeller manually.</li> <li>If 120 VAC is present during a call for heat, but the pump still does not circulate, replace pump.</li> </ul>
<b>Temperature Overshoot</b>	<ul style="list-style-type: none"> <li>Stack temperature has exceeded the limit temperature.</li> <li>Lockout: 82</li> </ul>	<ul style="list-style-type: none"> <li>The stack temperature has exceeded the maximum temperature allowed.</li> <li>Measure the resistance of the flue sensor at room temperature, it should be approximately 10kΩ.</li> </ul>
	<ul style="list-style-type: none"> <li>Outlet temperature has exceeded limit temperature.</li> <li>Alert: 79</li> </ul>	<ul style="list-style-type: none"> <li>Verify that the system is full of water and that all air has been properly purged from the system</li> <li>Verify that the boiler is piped properly. Refer to Piping Diagrams in Section 12 of this manual</li> <li>Verify that adequate power is supplied to pump on a call for heat. If voltage cannot be detected check wiring</li> <li>Verify pump is circulating when power is supplied. If so, pump impeller may be stuck.</li> <li>If power is present during a call for heat, but the pump still does not circulate, replace the pump.</li> <li>Replace the DynaForce Controller, if necessary.</li> </ul>
<b>Sensor Not Connected</b>	<ul style="list-style-type: none"> <li>Outlet sensor, Alert: 92</li> <li>Inlet sensor, Alert: 91</li> <li>Flue sensor, Alert: 95</li> <li>DHW sensor, Alert: 93</li> </ul>	<ul style="list-style-type: none"> <li>Verify sensors are connected</li> <li>Verify wiring.</li> <li>Measure resistance of sensors, 10kΩ sensors.</li> <li>Replace sensor if necessary</li> </ul>
<b>Fan Not Turning</b>	<ul style="list-style-type: none"> <li>Fan refuses to rotate</li> </ul>	<ul style="list-style-type: none"> <li>Check fan power wires</li> <li>Fan signal wires are interchanged</li> <li>Minimum fan speed must be greater than 2000 RPM</li> </ul>

SYMPTOM	FAILURE MODE	ANALYSIS
<b>Air Switch</b>	<ul style="list-style-type: none"> <li>• Air Switch error</li> <li>• Alert: 67</li> </ul>	<ul style="list-style-type: none"> <li>• Air Switch wire(s) is/are loose</li> <li>• Air Switch is set too tight, reduce sensitivity by turning screw ¼ turn counter-clockwise.</li> </ul>
<b>Flame Detection is out of Sync</b>	<ul style="list-style-type: none"> <li>• Flame detection is present when no visible signs of a flame exist</li> <li>• Lockout: 105, 158</li> </ul>	<ul style="list-style-type: none"> <li>• Verify supply voltage for proper polarity.</li> <li>• Check external wiring for voltage feedback</li> <li>• Check internal wiring for proper connections</li> <li>• Check the flame sensor and verify that it is clean</li> <li>• Replace DynaForce Controller</li> </ul>
<b>Blank Display Screen</b>	<ul style="list-style-type: none"> <li>• Blank display screen</li> </ul>	<ul style="list-style-type: none"> <li>• Check wire connections from DynaForce Controller to touchscreen display</li> </ul>
<b>Delta-T Limit Exceeded</b>	<ul style="list-style-type: none"> <li>• Inlet and Outlet temperature difference has exceeded 30°F</li> <li>• Alert: 550</li> </ul>	<ul style="list-style-type: none"> <li>• Check pump contact from DynaForce Controller</li> <li>• Check that adequate power is delivered to the pump</li> <li>• Pump impeller may be stuck. Use a flat head screwdriver on face of pump to turn impeller manually.</li> <li>• Purge all air from the piping.</li> </ul>



## PART 10 MAINTANANCE

### CAUTION

It is important that all gas appliances to be serviced by a Camus trained service technician. It is in your own interest and that of safety to ensure that all local codes, and all the "NOTES" and "WARNINGS" in this manual are complied with. To service or adjust this appliance, it is imperative that the Camus trained service technician utilize a combustion analyzer to read CO<sub>2</sub>, CO and flue pressure according to Camus Hydronics recommendation

### CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation

Listed below are items that must be checked to ensure safe reliable operations. Verify proper operation after servicing.

### 10.1 EXAMINE THE VENTING SYSTEM

Examine the venting system at least once a year. Check more often in the first year to determine inspection interval. Check all joints and pipe connections for tightness, corrosion or deterioration. Flush the condensate drain hose with water to clean. Clean screens in the venting air intake system as required. Have the entire system, including the venting system, periodically inspected by a qualified service agency.


### 10.2 VISUALLY CHECK MAIN BURNER FLAMES

At each start up after long shutdown periods or at least every six months. A burner view port is located on the burner mounting flange.

### CAUTION

The area around the burner view port is hot and direct contact could result in burns

Figure 37: Normal Burner Flame Profile (short dense and blue)



- Normal Flame: A normal flame at 100% of burner input is blue, with slight yellow tips a well defined flame and no flame lifting.
- Yellow Tip: Yellow tipping can be caused by blockage or partial obstruction of air flow to the burner.
- Yellow Flames: Yellow flames can be caused by blockage of primary air flow to the burner or excessive gas input. This condition **MUST** be corrected immediately.
- Lifting Flames: Lifting flames can be caused by over firing the burner, excessive primary air or high draft in excess of negative 0.15" W.C.

If improper flame is observed, examine the venting system; ensure proper gas supply and adequate supply of combustion and ventilation air.

### 10.3 FLUE GAS PASSAGEWAYS CLEANING PROCEDURES

Any sign of soot around the inner wrap, outer jacket, flue pipe connections, burner or in the areas between the fins on the stainless steel heat exchanger indicates a need for cleaning. The following cleaning procedure must only be performed by a qualified serviceman or installer. Proper service is required to maintain safe operation. Properly installed and adjusted units seldom need flue cleaning.

### NOTE:

All gaskets/sealant on disassembled components or jacket panels must be replaced with new gaskets/sealant on re-assembly. Gasket and sealant kits are available from the factory

### CAUTION

When the vent system is disconnected for any reason it must be reassembled and resealed according to vent manufacturer's instruction

### 10.4 CONDENSATION TREATMENT

This high efficiency appliance may operate as a condensing appliance for extended periods of time based on return water temperatures. Condensate occurs when the products of combustion are cooled below their dew point in the heat transfer process. The liquid condensate formed from this high efficiency heat transfer process is mildly acidic. The condensate will typically have a pH ranging from 4.0 to 5.0 as it is discharged from the condensate drain on the rear of the appliance. The internal jacket area where the condensate is collected (CHRM) is constructed from a special corrosion resistant stainless steel. All materials external to the appliance in contact with the condensate must be corrosion resistant. This is typically accomplished by using PVC plastic pipe and synthetic tubing. Condensate must be able to flow freely from the appliance. All condensate flow is accomplished by gravity requiring a minimum downward slope of 1/4" per foot (21mm/m) to ensure proper flow to the condensate management system and/or a suitable drain. The neutralizer **MUST** always be mounted on the same level or lower than the bottom of the appliance cabinet and downstream of the condensate trap. All condensate piping and connections must be easily accessible for routine maintenance and inspection.

#### 10.4.1 CONDENSATE VOLUME

There are several factors effecting amount of condensation created by the appliance CHRM, however for rough approximation use.

Condensation Volume, US Gallon/Hr = Input, MBH/1000 x 5.0

Many codes will require the acidic condensate to be neutralized before it can be placed in a drain system. A neutralizer to control the pH of the liquid discharged to a drain system is provided with every appliance. The neutralizer consists of an industrial grade, non-corrosive plastic reservoir for collection of the condensate. The condensate collects in the reservoir where it is in direct contact with the calcium carbonate. As the reservoir fills, it provides an extended residence time to neutralize the condensate. The neutralized condensate exits from the reservoir outlet. A 'P' trap must be installed upstream of neutralizer see Figure 6 above. Prime the installed assembly with water to prevent flue gas spillage from the drain. Use standard ½" vinyl, PVC, CPVC or suitable hose to run to floor drain.

When the condensate level in the reservoir rises to the drain, the pH is controlled to a range of 5.5 to 6.0 before exiting the system. (A pH of 7 is neutral. As the pH number increases in numerical value, the relative acidity of the discharge decreases). The neutralized condensate may then be discharged into a suitable drain system without fear of damage to the drain system. Always check with local codes for specific requirements. Neutralizers may be used in series to raise PH.

## 10.5 BURNER MAINTENANCE

The burner should be removed for inspection and cleaning on an annual basis. An appliance installed in a dust or dirt contaminated environment will require inspection and cleaning on a more frequent schedule. The fan assisted combustion process may force airborne dust and dirt contaminants, contained in the combustion air, into the burner. With sustained operation, non-combustible contaminants may reduce burner port area, reduce burner input or cause non-warrantable damage to the burner.

Airborne contaminants such as dust, dirt, concrete dust or dry wall dust can be drawn into the burner with the combustion air and block the burner port area. An external combustion air filter is provided with the appliance. An additional filter is located at the fan inlet and like the external filter may be washed in the sink under the tap. This internal filter should be checked and cleaned at the time of appliance commissioning and on a six month interval or more often in a contaminated environment.

### 10.5.1 BURNER REMOVAL AND CLEANING

Access to the burner will require the following steps:

- Turn off main electrical power to the appliance.
- Turn off main manual gas shutoff to the appliance
- Remove the top cover.
- Disconnect the gas supply connection to the fan inlet.
- Disconnect the fan motor power wires at the harness.
- Remove the hot surface igniter and the flame sensor.
- Remove the sensing tubes from the air ratio gas valve to the combustion air fan.
- Remove the 4 nuts holding the fan assembly to the heat exchanger and remove the fan assembly. On occasion the red silicone gasket may adhere to the underside of the fan's flange. Carefully pry the

flange away from the gasket prior to removing the fan assembly.

- The burner can now be lifted vertically out of the heat exchanger cavity. A ceramic paper gasket is located directly under the burner flange. This gasket must be replaced if it is damaged.
- Use care to prevent damage to the knitted metal fiber of the burner surface.
- Wash the burner with low pressure water. Never wipe or brush the surface of the burner nor use high pressure water or air.
- Check all gaskets and replace as necessary. Gaskets affected by heat will not reseal properly and must be replaced.
- Replace the burner in the reverse order that it was removed. Insert the igniter and sensor before doing the final tightening on the fan mounting nuts. Evenly tighten the nuts to 20 ft-lbs.

## NOTE:

When the combustion air fan is removed for any reason, the inlet to the burner must be covered to prevent further foreign objects from falling into the burner. Always look inside the burner to check for dents. Do not place a burner back into operation if the inner distribution screen has been dented during the service operation, call the factory for recommendations. Use care when removing and handling the burner, Sharp objects or impact may damage or tear the metal fiber surface rendering the burner unfit for service.

### 10.5.2 BURNER CLEANING PROCEDURE

Remove any visible dust or dirt blockage from the surface of the burner using water from a garden hose. The burner may best be cleaned by immersing the burner port area in a solution of dishwashing detergent and hot water. Allow the burner to remain in the solution for a short period of time to remove dust, dirt and oil or grease laden contaminants. Rinse the burner thoroughly with clean water to remove any residue from the detergent cleaner. The burner should be air dried after removal from the cleaning solution and rinsing. **DO NOT** use chlorine based solvents or cleaning agents on the burner.

### 10.6 CHANGING THE HOT SURFACE IGNITER

- The hot surface igniter is to be checked at least after every 4000 hours of operation and more frequently under high cycling conditions. This will maintain peak ignition efficiency.
- Turn off main electrical power to the appliance.
- Turn off main manual gas shutoff to the appliance.
- Locate the Hot Surface Igniter.
- Disconnect the two power leads to the hot surface igniter.
- Loosen and remove the two screws that hold the igniter.
- Lift the igniter vertically out of the burner mounting flange. Use care, do not hit or break the silicon carbide igniter. **DO NOT** pull out by leads.
- Ensure that the ceramic paper gaskets used to seal the base and top of the igniter are reinstalled on the new igniter.

### 10.6.1 RE-INSTALLING THE IGNITER

- Confirm that the end of the replacement igniter has a bead of silicone sealing the gap between the metal mounting flange and the ceramic shaft of the igniter.
- Carefully insert the igniter into the mounting point on the burner flange and push into position on top of the fan's flange. The word 'OUTSIDE' on igniter faces you when inserting igniter.
- Reinstall the two mounting head screws and tighten by hand only.
- Ensure that the igniter ceramic paper gaskets are properly installed and seal the point of contact between the igniter and fan mounting flange.
- Reconnect the power leads to the igniter.
- Turn on main gas supply.
- Turn on main power.
- Test fire the appliance to ensure proper operation.
- The igniter must generate 3A to reliably prove the ignition system.

### 10.7 HEAT EXCHANGER INSPECTION

- The heat exchanger should be inspected at the time of burner maintenance.
- Turn off all power to the appliance.
- Turn off main gas to the appliance.
- Remove top cover.
- Remove fan assembly and burner as detailed in the Burner and Cleaning section.
- Check the heat exchanger surface for soot. If soot is present, heat exchanger must be cleaned and problem corrected.
- Remove the front outer jacket door.
- Check "V" baffles on the exchanger.
- Use detergent water pressure wash to remove soot from heat exchanger and surfaces of the inner chamber.
- When necessary, the heat exchanger can be removed by disconnecting all water piping and removing the eight flange mounting bolts at the rear of the appliance. The heat exchanger can now be removed from the front of the appliance.
- Reinstall inner jacket door. Replace any damaged gaskets to ensure a proper air seal.
- Reinstall the burner and fan assembly.
- Reassemble all gas and water piping. Test for gas leaks.
- Reassemble outer jacket panels. Keep top cover off.
- Cycle unit and check for proper operation.
- Once proper operation is confirmed replace the top cover.

### 10.9 RE-INSTALL HEAT EXCHANGER

- Carefully reinstall the heat exchanger if removed from the appliance.
- Check all gaskets and replace if damaged.
- Replace heat exchanger cover.
- Reassemble outer jacket panels.
- Cycle unit and check for proper operation.
- Replace the top cover

### 10.10 COMBUSTION AIR FAN

Combustion air fan should be checked every 6 months. Clean internal filter to fan as required when installed in a dust or dirt contaminated location. See Combustion Air Fan in the component section for cleaning procedure. The motor and bearings on the combustion air fan are sealed and permanently lubricated requiring no addition of oil or lubricants.

### 10.11 COMBUSTION AND VENTILATION AIR

Check frequently to be sure that the flow of combustion and ventilation air to the appliance is not obstructed.

Combustion and ventilation air must be provided to the mechanical room with openings sized per the requirements of the B149 or National Fuel Gas Code. The optional outdoor air kit brings combustion air from the outdoors directly to the appliance.

### 10.12 CONTROL CIRCUIT VOLTAGE

This appliance uses a transformer to supply a low voltage control circuit. The voltage on the secondary side should be 24 to 28VAC when measured with a voltmeter. A secondary voltage of 21VAC or less supplied to 24VAC components may cause operational problems. A 4A circuit breaker is provided on the secondary side of the transformer. The circuit breaker is located on the front control panel. A tripped circuit breaker indicates a short in the 24VAC controls and must be corrected.

### 10.13 COMBUSTIBLE MATERIALS

#### CAUTION

Keep appliance clear from combustible materials; do not store **GASOLINE** and other flammable vapors and liquids in the proximity of the appliance.

### 10.14 FREEZE PROTECTION

Installations are not recommended in areas where the danger of freezing exists. Proper freeze protection must be provided for appliances installed outdoors, in unheated mechanical rooms or where temperatures may drop to the freezing point or lower. If freeze protection is not provided for the system, a low ambient temperature alarm is recommended for the mechanical room. Damage to the appliance by freezing is non-warrantable.

- **Location** - Heating boilers, hot water supply boilers or water heaters must be located in a room having a temperature of at least 50°F (10°C)
- **Caution** - A mechanical room operating under a negative pressure may experience a downdraft in the flue of an appliance that is not firing. The cold outside air may be pulled down the flue and freeze a heat exchanger. This condition must be corrected to provide adequate freeze protection.
- Freeze protection for the appliance using an indirect coil can be provided by using hydronic system antifreeze. Follow the manufacturer's instructions. **DO NOT** use undiluted or automotive type antifreeze.
- **Shut-down and draining** - If for any reason, the unit is to be shut off in a space where danger of freezing exists, the following precautionary measures must be taken:
  - Shut off gas supply.
  - Shut off water supply.
  - Shut off electrical supply.

- Drain the main exchanger and the secondary exchanger, if supplied, completely.
- Ensure that the pump and connecting piping are fully drained.

### 10.15 **FREEZE PROTECTION FOR A HEATING BOILER SYSTEM (Optional)**

- Use only properly diluted inhibited glycol antifreeze designed for hydronic systems.
- Follow the instructions from the antifreeze manufacturer. Quantity of antifreeze required is based on total system volume including expansion tank volume.
- Antifreeze is denser than water and changes the viscosity of the system. The addition of antifreeze will decrease heat transfer and increase frictional loss in the boiler and related piping. Where antifreeze has been used, to maintain the temperature rise across the appliance confirm that the recommended GPM for pure water has been increased by 15% and the head loss by 20%.
- Local codes may require a back flow preventer or actual disconnect from city water supply when antifreeze is added to the system.
- When filling or topping-up the system with water mixed with the antifreeze always use distilled or RO (reverse osmosis) water. This will prevent the reaction of the water with antifreeze which can create sludge.

## PART 11 INSTALLATIONS

### WARNING

Before starting the boiler, smell near the floor and around the boiler for any gas odours or any unusual odour. Remove the stainless steel jacket and smell the interior of the boiler. If there is any sign of a gas leak, do not proceed with startup. Repair all the leaks before attempting to start the boiler

### WARNING

Propane boilers ONLY – Your local propane supplier adds an odorant to the propane gas to allow for propane gas leak detection. In some cases, the added odorant can fade and the gas may not give off any noticeable odour. Before startup have the local propane supplier check for the correct odorant level in the gas.

### 11.1 CHECKING THE INSTALLATION

- Inspect the connections for water, gas and electricity.
- Inlet gas pressure must be a minimum of 3" W.C. for natural gas and 11" W.C. for propane.
- With the boiler off, open the main gas supply valve and vent the trapped air from the piping leading to the boiler. Confirm that all gas connections to the heater are tight and that there are no missing test plugs.

Refer to Section 8.3 Gas Valve Adjustment Procedure of the manual for recommendations on setting combustion characteristics

### 11.2 CHECKING THE INSTALLTION

- Check the boiler wiring to see that it agrees with the wiring diagram supplied.
- Confirm that all terminal strips and field connections are identified.
- Confirm that the DynaForce Controller control is set in the proper mode. In remote mode an external controller determines the set point and the stage contacts on the DynaForce Controller are always closed. Auto reset limits are fixed in all Modes.
- With the boiler running, check for flue gas leaks along the inner cabinet joints and around the flue outlet.
- Repair any leaks prior to proceeding to the next step.
- At the factory, adjustments were made to achieve proper input and acceptable burner performance at full input and at minimum input.

### 11.3 INSPECT & RECHARGE CONDENSATE COLLECTION/ NEUTRALIZING RESERVOIR

- 1) Inspect the condensate reservoir in the DynaMax, making sure the collection box is intact.
- 2) Remove screw holding lid on to condensate collection box. Remove lid from the condensate collection box
- 3) Examine neutralizer medium and refill as necessary with fresh medium
- 4) Fill with fresh water until the water begins to flow out of drain

- 5) Re-install the lid and hold-down screw on the condensate collection box.

**WARNING**

The condensate collection box must be filled with water to prevent flue gas emissions from escaping during boiler operation.

**CAUTION**

A leak in a boiler "System" will cause the fill system to introduce fresh water constantly, which may cause the tubes to accumulate a line/scale build up. Lime/scale buildup leading to heat exchanger failure is **NOT** covered by warranty.

**11.4 HEATING BOILER INSTALLATIONS**

The appliance **MUST** always be installed in a primary/secondary piping system for proper operation. Before beginning the installation, consult local codes for specific plumbing requirements. The installation should provide unions and valves at the inlet and outlet of the appliance so it can be isolated for service. An air separation device must be supplied in the installation piping to eliminate trapped air in the system. Locate a system air vent at the highest point in the system. The system must also have a properly sized expansion tank installed. Typically, an air charged diaphragm-type expansion tank is used. The expansion tank must be installed close to the boiler and on the suction side of the system pump (appliance Inlet) to ensure proper operation. Caution: This appliance should not be operated at less than 15 PSIG cold. Pressure will rise when hot. Expansion tank sizing will determine the pressure when the system is hot. Do not operate the system at less than 30 PSIG when hot. Water piping must be supported by suitable hangers or floor stands, **NOT** by the appliance. Pipe systems will be subject to considerable expansion and contraction. Pipe supports could allow the pipe to slide resulting in noise transmitted into the system. Padding is recommended. The boiler pressure relief valve must be piped to a suitable floor drain. See Section 4.2.

**CAUTION**

A leak in a boiler "System" will cause the "System" to intake fresh water constantly, which will cause the tubes to accumulate a line/scale build up. This will cause a **NON-WARRANTABLE FAILURE**.

**11.5 WATER CONNECTIONS**

All models have FIP inlet and outlet bronze connections. Pipe size must be in accordance with Table 4 and, between supply and return lines, must not exceed 80 feet of equivalent length. Any reduction in recommended pipe size may decrease flow resulting in high water temperatures, boiler noise, flashing to steam and non-warrantable heat exchanger damage.

**11.6 PIPING LENGTHS**

The appliance circulator provides the water flow from the primary boiler piping, through the boiler and back to the primary system. Pipe diameter and length are critical to ensure proper flow through the boiler. The secondary loop piping to and from the appliance must have a fully ported ball valve installed in both the inlet and outlet side piping and will be used for isolation only. The ball valves must be the same diameter as the installed piping. If flow control is required, other means of flow

control such as globe valve or flow setter should be used.

**11.7 INTERMITTENT PUMP OPERATION**

An intermittent pump operation signal is standard and can be used to operate a separate pump contactor. A ¼ hp pump delay relay is available as an option. When equipped with this option, the boiler's integral circulating pump will cycle on at each call for heat, before the burner fires. The pump will continue to operate while the burner is firing. The pump will run for a period of time until the programmed delta T between inlet and outlet is reached, after the temperature set point is satisfied. This will remove any residual heat from the combustion chamber before turning the pump off. See wiring diagram shipped with the unit.

**11.8 SUMMARY**

**a) Typical Boiler Installations**

**General Plumbing Rules**

- 1 Check all local codes.
- 2 For serviceability of boiler, always install unions.
- 3 Always pipe pressure relief valve to an open drain.
- 4 Locate system air vents at highest point of system.
- 5 Expansion tank must be installed near the boiler and on the suction side of the system pump.
- 6 Support all water piping.

**b) Placing the Boiler in Operation**

**Pre-Start Check List**

- 1 Review the location of the boiler, clearances from combustible surfaces and available service clearances.
- 2 Review Part 2 Venting. Ensure that all vent components are fabricated from the correct category of materials with adequate clearance from combustibles.
- 3 Ensure that the boiler condensate drain and all vent system condensate drains are properly routed to an acceptable floor drain or neutralization system.
- 4 Review the vent termination point for proper location and clearances.
- 5 Ensure that proper volumes of combustion and ventilation air are provided to the mechanical room. If a separate combustion air pipe is used, ensure that it is properly sized, sealed and terminated.
- 6 Review the water piping from the boiler to the system. The boiler must be installed in a primary/ secondary piping system. Review the diameter and equivalent length of the installed piping to and from the boiler to ensure proper flow.
- 7 Ensure that a properly sized primary system pump is installed with an expansion tank.
- 8 Check system pressure. Ensure a minimum of 30 PSIG with the system hot and not more than 90% of the rated pressure of the relief valve.
- 9 Review the installed gas piping from the meter to the boiler. Ensure that the gas pipe, meter and any regulators are adequately sized.
- 10 Review the field wiring and electrical service for both the boiler controls and pump. Ensure that the electrical service(s) is adequately sized.

### **Boiler Set-Up**

- 1 Ensure that the boiler and piping system are full of water. Bleed all air from the pump housing and secondary loop.
- 2 Check system for any water leaks.
- 3 Check system for installation of glycol or water treatment where required. Where glycol has been used to maintain the temperature rise across the appliance confirm that the recommended flow for pure water has been increased by 15% and the head loss by 20%.
- 4 Turn on power to the primary system pump and the appliance secondary pump and verify operation.

### **Boiler Operational Checks**

- 1 Turn the boiler main power switch to the "ON" position.
- 2 Program the adjustable points.
- 3 Turn the switch to the "ON" position to start boiler operation.
- 4 Push the resets for low water level, high water temperature and flame failure.
- 5 Install a manometer on the gas supply to the boiler and verify minimum gas supply pressure as the burner fires at 100% of rated input.
- 6 Verify operation of safeties as necessary (low water cut-off, high limit, gas pressure, etc.).

### **Boiler Operation**

- 1 Appliance should begin the start-up process for the sequence of operation.
- 2 The boiler will fire down to 20% on initial start-up and adjust input as required to meet system demand.
- 3 Based on system demand, the appliance will modulate accordingly.
- 4 As system demand is satisfied, the burner will cycle off and the combustion air fan will decelerate at a pre-programmed rate before the appliance shuts down.

## **11.9 DOMESTIC HOT WATER HEATER**

Hot water heaters are designed for installation with a storage tank. The operation of the properly sized circulating pump, the piping between the tank and heater and the control of water velocity, as explained below, are important for correct operation of your hot water heater.

### **11.10 WATER VELOCITY CONTROL**

To ensure proper velocity through the heat exchanger(s), it is necessary to select the proper pump. Temperature rise at full fire will be an indication of flow. This must be done on initial installation and periodically rechecked.

Excessive lime/scale build-up in the heat exchanger tubes is a result of restricted flow and too little velocity in the tubes. Care should be taken to maintain required water velocity based on water condition as follows:

#### **11.11 TEMPERATURE RISE AT FULL FIRING RATE**

- 1 The pump must run continuously when the burner is firing.
- 2 With the pump running and the burner in the water

heater or hot water supply boiler in the off cycle, the inlet temperature and outlet temperature readings on the SmartFlame display should read approximately the same temperatures.

- 3 Turn the hot water heater on and allow time for the temperature to stabilize. Check the temperature rise when the burner is firing at 100% of rated input.
- 4 Compare the temperature rise on the SmartFlame display with the required temperature rise at the required flow rate based on water condition (Soft, Normal, and Hard). Should adjustment be needed, proceed as follows:

#### **If the temperature rise is too high, the water velocity is too low. Adjust as follows:**

- 1 Check for flow restrictions. Check for debris in strainers
- 2 Check diameter and equivalent length of the piping between the storage tank and hot water heater.
- 3 Be sure all valves are open between the hot water heater and the storage tank. Ensure that all ball valves are fully ported.
- 4 Check the pump to be sure it is running properly and that the pump motor is running in the proper direction.
- 5 Be sure the pipes between the hot water heater and storage tank are not more than a total of 80 equivalent feet between inlet and outlet lines. If maximum equivalent length for the specified pipe diameter is exceeded, larger diameter pipe may have to be installed to achieve correct flow and temperature rise.
- 6 Common manifold piping for multiple unit installations will require larger minimum pipe sizes and tank circulating tapping to ensure proper flow.

#### **If the temperature rise is too low, the water velocity is too high. Adjust as follows:**

- 1 Temperature rise can be increased by slowly closing the flow control valve (globe valve or flow setter) in the outlet piping from the hot water heater to the storage tank to achieve the proper temperature rise.
- 2 Sustained high water velocity and low temperature rise may result in pitting or erosion of the stainless steel tubes in the heat exchangers. This is a non-warrantable failure. Temperature rise must be properly adjusted to achieve the specified flow rate.

The required temperature rise and the recommended pump size are based on the heating of potable water with a hardness of 7.5 to 17.0 grains per gallon and a total dissolved solids not exceeding 300 PPM. Consult the factory when heating potable water exceeding these specifications. Water with a hardness of less than 5 grains per gallon will usually have a low pH which can be aggressive and corrosive causing non-warrantable damage to the heater, pump and associated piping. Corrosion due to water chemistry generally shows up first in the hot water system because heated water increases the rate of corrosive chemical reactions.

#### **CAUTION**

Temperature rise cannot be adjusted when the burner is firing at less than 100% of input rate.

### **11.12 WATER HEATERS**

The manufacturer recommends the use of a properly sized thermostatic mixing valve to supply domestic hot water at temperatures less than 140°F (60°C). Storing the water at a higher temperature and thermostatically mixing the water will decrease the size of the storage tank and increase the


available quantity of mixed hot water.

Caution! Adequate care **MUST** be taken to prevent potential scald injury when storing water at 140°F (60°C) and hotter.


**WARNING**

Should overheating occur or the gas supply fail to shut off, do not turn off or disconnect the electrical supply to the pump, instead, shut off the gas supply at a location external to the appliance



# PART 12 EXPLODED VIEW







View "C"



View "B"




Ref #	Name of Part	Part ID	DynaForce Models																		
			ALL	300	350	400	500	600	800	1000	1200	1400	1600	1800	2000	2500					
1	Heat Exchanger	300		X																	
		350			X																
		400				X															
		500					X														
		600							X												
		800								X											
		1000									X										
		1200										X									
		1400											X								
		1600												X							
		1800													X						
		2000														X					
		2500															X				
		3000																X			
		3500																	X		
		4000																		X	
		4500																			X
5000																				X	
2	Main Burner	300-BRN		X																	
		350-BRN			X																
		400-BRN				X															
		500-BRN					X														
		600-BRN						X													
		800-BRN								X											
		1000-BRN									X										
		1200-BRN										X									
		1400-BRN											X								
		1600-BRN												X							
		1800-BRN													X						
		2000-BRN														X					
		2500-BRN															X				
		3000-BRN																X			
		3500-BRN																	X		
4000-BRN																		X			
4500-BRN																			X		
5000-BRN																				X	
3	Igniter	Precision Speed		X	X	X	X	X	X	X	X										
		271R										X	X	X	X	X					
		Proven Pilot																			
4	Flame Rod	66-0023	X																		
5	DynaForce Controller	R7910A	X																		
Ref	Name of	Part ID	DynaForce Models																		

#	Part		ALL	300	350	400	500	600	800	1000	1200	1400	1600	1800	2000	2500	3000	3500	4000	4500	5000	
7	Combustion Fan	55667.21200		X	X	X																
		55667.14002					X															
		G1G170						X	X	X												
		AF9									X	X	X	X								
		AF10														X	X					
		AF12																X	X	X	X	
		AF15																				X
8	Electrical Motor	1/2HP									X	X										
		1 HP											X	X	X							
		1 1/2 HP														X	X					
		3 HP																X	X	X	X	
8	Venturi	45900450-010		X	X	X																
		VMU300A1046					X	X	X	X												
		Camus Design									X	X	X	X	X	X	X	X	X	X	X	
9	Gas Valve	VR8615B1044		X	X	X																
		V8730C1015					X															
		V8730C1023						X	X													
		V8730C1031								X	X	X										
		V4734C1002											X	X								
		SKP 55													X	X	X	X	X	X	X	
10	Gas Valve Regulator	SKP25												X	X	X	X	X	X	X		
12	Filter Holder	GFH-300-CH		X																		
		GFH-400-CH				X																
		GFH-500-CH					X															
		GFH-600-CH						X														
		GFH-800-CH							X													
		GFH-1000-CH								X												
		GFH-1200-CH									X											
		GFH-1400-CH										X										
		GFH-1600-CH											X									
		GFH-1800-CH												X								
		GFH-2000-CH													X							
		GFH-2500-CH														X						
		GFH-3000-CH															X					
		GFH-3500-CH																X				
		GFH-4000-CH																	X			
		GFH-4500-CH																		X		
GFH-5000-CH																			X			
13	Rear Fan Intake Filter	GFIF-1200-CH									X											
		GFIF-1400-CH										X										
		GFIF-1600-CH											X									
		GFIF-1800-CH												X								
		GFIF-2000-CH													X							







Note: 1) If any of the original wire as supplied with the appliance must be replaced. It must be replaced with wiring having a temperature rating of at least 105°C

DRAWN		NOV-5-2009	
CHECKED			
<b>CAMUS HYDRONICS LIMITED</b>			
<b>2500 - 4500 DYNAFORCE</b>			
SIZE		REV	
SCALE		00	
99-0138			
SHEET 1		OF 1	

This drawing is the property of Camus Hydraulics Limited. It is not to be used or copied without the prior written consent of Camus Hydraulics Limited.





**CAMUS Hydronics is a manufacturer of replacement parts for most copper finned**

**water heaters and heating boilers as well as a**

**supplier of specialty HVAC products. Our service line is open 24 hours, 7 days a week!**

**The CAMUS CERTIFIED! Seal assures you that Reliability, Efficiency & serviceability are built**

**into every single unit! For more information**



**on our innovative products from CAMUS Hydronics Limited, call 905-696-7800 today.**



**CAMUS HYDRONICS LTD.**  
**6226 Netherhart Road, Mississauga, Ontario L5T 1B7**  
**TEL: 905-696-7800 FAX: 905-696-8801**